


ASSEMBLY INSTRUCTIONS



Fine Furniture for every stage of life

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.

ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


A	SEAT		1PC
B	SIDE FRAME		2PCS
C	SMALL CROSSBAR		2PCS
D	LARGE CROSSBAR		2PCS

Z HARDWARE IDENTIFICATION


NO	DESCRIPTION	FIGURE	Q' TY
1	ØALLEN KEY 5mm		1PC
2	ØBOLT 5/16X1-3/4"		4PCS
3	ØLOCK WASHER 5/16"		4PCS
4	ØWOOD CAP 15X19MM		4PCS
5	ØSCREW 8X1-3/4"		10PCS

ASSEMBLY INSTRUCTIONS

STEP: 1



STEP: 2



STEP: 3

