



FOR REPLACEMENT PARTS OR HELP WITH ASSEMBLY PLEASE CONTACT US

PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR INSTRUCTION BOOKLET

TO RETURN THE PRODUCT:

PLEASE CONTACT THE RETAILER

WHERE THE ITEM WAS PURCHASED FROM

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

CARE and MAINTENANCE

To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.

Do not use ammonia-based cleaning products, as they will damage the finish. Do not leave liquids or damp cloths on this furniture.

To avoid dulling of the finish, do not place furniture in direct sunlight. Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.

PRE-ASSEMBLY INFORMATION PART DESCRIPTION A B TOP QTY 1 LEG QTY 4

NEED HELP? For help with assembly or if you are missing a part, Please call customer service

PRE-ASSEMBLY INFORMATION

HARDWARE DESCRIPTION

ALLEN KEY BOLT
M6 X 80mm
QTY 8 SETS

ALLEN KEY
QTY 1

ALLEN KEY
QTY 1

ALLEN KEY
QTY 1

ALLEN KEY
QTY 3


ALLEN KEY
QTY 1

QTY 3 SETS



Required -Flathead screwdriver Phillips screwdriver **Not Included**

NEED HELP? For help with assembly or if you are missing a part, Please call customer service




ASSEMBLY STEP-1 0 0 00 $^{\otimes}$ $^{\otimes}$ B

- 1. Remove the drawers from to compartment.
- Attach Legs B to Top A.
 Use eight sets Allen Key Bolt 1 to secure part A and B (two sets on each Leg).
 Use Allen Key 2 to tighten Allen Key Bolts. Do not over-tighten.

ASSEMBLY

STEP-2



- 1. Attach three Handles 3 to the Drawer Fronts of the Top A.
- 2. Use Phillips screwdriver to tighten screws. Do not over-tighten.
- 3. Insert the Drawers into Top Compartment.

WARRANTY

Thank you for purchasing our product.

These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.)

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.