

Arched Bookcase with Glass Doors


Assembly Instruction



2 Person Required



Tools Included






Customer Support

NEED HELP? For replacement requests or product inquiries, please contact our Customer Service Team by emailing us**.** Thank you for selecting us!

⚠ WARNING






Children have died from furniture tipover.
To reduce the risk of furniture tipover:
-ALWAYS install Anti-tip device provided.
-NEVER put a TV on this product.
-NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!


TIPPING RESTRAINT HARDWARE

Note: We have included two Tipping Restraint Hardware set for this Unit. When properly installed, this restraint can provide protection against the unexpected tipping of the Unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your Unit.

Note: You must install the Tipping Restraint Hardware with the unit in use to prevent any accidents or damage to the unit.




















PART LIST











USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using uncompatible hardware might cause damage to product.

PART LIST			
A x 2pcs 	B x 1pcs 	C x 2pcs 	D x 1pcs 
E x 1pcs 	F x 1pcs 	G x 1pcs 	H x 1pcs 
I x 1pcs 	J x 1pcs 	K x 2pcs 	L x 1pcs 
M x 1pcs 	N x 1pcs 	O x 1pcs 	P x 1pcs 
Q x 1pcs 			


HARDWARE LIST

①  M6x28 42 pcs	②  Φ12 42 pcs	③  Φ6x30 24 pcs
④  M6x20 8 pcs	⑤  M4x14 72 pcs	⑥  12 pcs
⑦  M4x12 42 pcs	⑧  4 pcs	⑨  M4x20 4 pcs
⑩  8 pcs	⑪  M4x40 2 pcs	⑫  1 pcs

How to install Camlocks


Connect the male camlock as directed in the assembly instructions with a screwdriver.

1 DO NOT OVER TIGHTEN



Put the male camlock into the entry hole.


2



Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points toward the entry hole for the male camlock.

3




Screw the female camlock clockwise with a screwdriver.

You will feel a click when the camlock is locked in place.


The camlock is now completed.

4




HOW TO ADJUST THE EUROPEAN ADJUSTABLE HINGES ON DOOR


If the doors require adjustment, follow the below options as needed:
To adjust door up or down, loosen screws (a), adjust door and retighten screws.
To adjust door left and right, turn screw (b) in or out.
To adjust door in and out, loosen screw (c), adjust door and retighten screw.




STEP 1


1
x8
1
1
B
1
1
1
1
J
1
1


STEP 2


2
x4
Keep the holes of the Part A toward this direction as shown
A
2
2
A
B


STEP 3


1 x16
1
1
1
1
E
1
1
1
D
1

STEP 4



2 x16
3 x8
Keep the holes of the
Part A/C/D/E toward this
direction as shown
E
C
2
2
2
A
B
2
A
D
3
2

STEP 5




Gently tap the Floor Protectors (10) at the bottom of side panels avoiding crack or damage of side panels.

STEP 6





STEP 7

Keep the holes of the Part F toward this direction as shown




STEP 8







STEP 9




STEP 10




STEP 11




STEP 12




STEP 13




STEP 14




STEP 15



STEP 16






There are no reserved holes for two front screws, please use tools to screw directly.


5 x48

Methods to Adjust Hinges to Reduce Door Gaps




LATERAL ADJUSTMENT

by screw adjustment.



FRONT-TO-BACK

by loosening and retightening the hinge arm mounting screw.




VERTICAL ADJUSTMENT


via slots on the mounting plate by slackening and retightening the screws.

Please refer to page 6, which contains detailed adjustment steps.


STEP 17



STEP 18



STEP 19



TIPPING RESTRAINT HARDWARE

Note: We have included two Tipping Restraint Hardware set for this Unit. When properly installed, this restraint can provide protection against the unexpected tipping of the Unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your Unit.

Note: You must install the Tipping Restraint Hardware with the unit in use to prevent any accidents or damage to the unit.

