

Installation Notes

Steps for Pairing Remote Control

After receiving the remote control, you must pair it with the light to adjust the light color.



Step 1

- Turn on the wall switch.



Step 2

- Press and hold the "CCT Change" button (Keep pressing for 5 seconds).



Step 3

- The light flashes and a beep is heard, indicating that the pairing was successful.