

ASSEMBLY INSTRUCTIONS

MODEL : DINING CHAIR

Thanks you for purchasing this quality product. Be sure to lay all components on a soft and clean surface before assembly in order to avoid components from being scratched.


CAUTIONS :

1. Check contents against list for quantity.
2. Familiarize yourself with the components and hardware by reviewing the Assembly Instructions.
3. Do not over tightened the screws and bolts as it may damage the threads.
4. Keep all hardware parts out of the reach of children.
5. Please "LIFT UP & MOVE" the chair when ever you want to shift it.



PARTS LIST		
NO.	DESCRIPTION	QTY
1	CHAIR BODY 	1 PC
2	BACK LEG 	2 PCS
3	FRONT LEG 	2 PCS

HARDWARE LIST		
NO.	DESCRIPTION	QTY
A	JCBC M6 x 50MM 	8 PCS
B	SPRING WASHER 	8 PCS
C	FLAT WASHER 	8 PCS
D	ALLEN KEY M4 	1 PC

STEP 1



STEP 2



Put up the chair on the floor, make sure legs are in even position and tighten the JCBC bolt.

COMPLETED ASSEMBLY