


INSTALLATION INSTRUCTIONS

DeerValley®

Bathroom Intelligent Medicine Cabinet



- Please read these instructions carefully to familiarize yourself with the required tools, materials, and installation sequences. Follow the sections that pertain to your particular installation. This will help you avoid costly mistakes. In addition to proper installation, read all operating and safety instructions.
- These instructions contain important care, cleaning, and warranty information.
- Before installation, carefully inspect the new fixture for any signs of damage.



WARNING: Risk of injury or product damage. Be careful when opening the door to avoid pinching fingers.



WARNING: Do not use acidic or alkaline cleaners or alcohol to clean the surface. Use a dampened cloth to clean.



CAUTION: Risk of electric shock. Electrical wiring may need to be relocated.

Grounding Instructions:

This product should be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.



WARNING: Risk of electric shock. Improper use of the grounding plug can result in a risk of electric shock.

- If repair or replacement is required, it must be completed by qualified maintenance personnel.
- This product is equipped with specific wires from the factory. If the product is used together with other products, consideration should be given to wiring issues, and connections should be made by qualified service personnel.

**If you have any questions or concerns
please contact us:**

(312)626-9466

service@deervalleybath.com

Double Touch Switch

Short press: Defogging/Bluetooth signal on or off. The backlight of the button is white when the defogging/Bluetooth signal is turned on, and blue when it is turned off. The defogging/Bluetooth function will automatically turn off after 60 minutes of activation, and the button backlight will turn white. If the user still needs to use the defogging function, it must be manually turned on again.

Light Control: To turn the light on or off, touch the switch on the bathroom mirror with your finger (tap). The light will change color with each tap. Touch the switch on the bathroom mirror with your finger for more than 5 seconds. The light will change luminance.



Required Tools(Not Included)



Electric Drill



Drill Bit (Φ0.3 in)



Tape



Pencil



Spirit Level

Supplied Spare Part



Wall Plugs x3



Screws x3



Hanger x1



Tempered Glass Shelves x4



Laminated glass clip x16



connecting terminal x3

ELECTRICAL SAFETY INSTRUCTIONS

All connections must be installed by a licensed electrician in accordance with current building codes. Consult a qualified electrician.


INSTALLATION CARE & SAFETY

Wear suitable eye protection when drilling. Take care when using power tools. Beware of hidden cables or pipes. Take care when drilling on tiled surfaces to prevent the drill from slipping. Applying a piece of masking tape to the wall before marking out the fixing holes will help stop the drill from wandering.


IMPORTANT

DO NOT strike glass components with hard or pointed items. DO NOT place very hot or very cold items against or in close proximity to glass surfaces unless an adequately thick insulation material is used to prevent such items from coming in contact with the glass. If the glass becomes chipped or broken, replace it immediately.


1. Remove the product from the packaging and take out the hanging strip.




2. Align the hanging strip with the desired location on the wall and mark the positions of the holes.



3. Drill the required holes and insert wall plugs.




4. Screw the bracket to the wall using the screws, and adjust it with a spirit level.




Option 1: Plug-in Installation

5-1. Insert the plug directly into the standard socket (pay attention to electrical safety)




Option 2: Hardwired Installation


5-2. Disconnect the plug and connect the product wire to the power supply through the wire connector (pay attention to electrical safety)




6. Hang the cabinet on the wall bracket. Ensure the claws on the cabinet hangers are securely located on the wall bracket. The position of the cabinet can be adjusted approximately 0.39in to the left or right. Note that due to the large size, two people are needed to install it simultaneously.




A




B




7. Take out the glass clips and laminated tempered glass from the packaging accessories. Install the glass clips on both sides.




8. After installing the laminated glass, adjust its position to center it. Tighten the glass clips with a screwdriver to secure the laminated glass.




9. Adjust the cabinet door




Mirror Cabinet Door




Mirror Cabinet Door



Mirror Cabinet Door



Bluetooth Connection Instructions



1. Turn on the Bluetooth switch.
2. Enable Bluetooth on your smartphone or other Bluetooth-enabled device.
3. Search for and select the device named "K1" to complete pairing.

Function Overview:

Play music wirelessly through Bluetooth after pairing.

Optional Bluetooth Control:

Control music volume, change songs, pause and play music, and perform other operations through your mobile device.

LIMITED WARRANTY COVERAGE

1-YEAR LIMITED WARRANTY

DeerValley products are made with quality materials and excellent craftsmanship to provide customers with a long-lasting product. If any defects in materials or craftsmanship are found under normal use within the first year of delivery, DeerValley will provide replacement parts at no charge or, at its option, replace any product or part of the product deemed defective under normal installation, use, service, and maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required to process any claims. **SCRATCHES ARE NOT COVERED UNDER WARRANTY.**

The manufacturer warrants that this product will be free from manufacturing defects for the duration of the above-mentioned warranty period. Please retain a copy of the original invoice as proof of purchase.

DeerValley will, at its option, (1) repair or replace the defective part(s) or product(s) at no charge; (2) issue a refund for the original purchase price of the product(s) (valid within 30 days from the date of delivery); or (3) issue a credit to be applied toward the purchase of a new DeerValley product. Shipping/delivery charges may apply and are at DeerValley's sole discretion.

DeerValley recommends that installations be performed by a licensed, professional plumber. DeerValley will not be held responsible for any damage or product failure resulting from improper installation, misuse, or failure to hire a licensed professional. Additionally, DeerValley is not responsible for any removal or installation costs.

This limited warranty does not cover goods that have been subjected to accidents, negligence, improper installation, product abuse, product misuse, or the use of cleaners containing abrasives, alcohol, or other organic solvents. Such exclusions apply regardless of whether the actions were performed by a contractor, service company, or the purchaser.

DeerValley's responsibility under this limited warranty is limited solely to the replacement of parts and does not cover any other costs. DeerValley will not be responsible for labor charges or any damage incurred during installation, repair, or replacement, nor for any indirect, incidental, or consequential damages, losses, injuries, or costs of any kind related to this product. Except as required by law, this limited warranty replaces and excludes all other warranties, conditions, and guarantees, whether expressed or implied, statutory or otherwise, including but not limited to those regarding merchantability or fitness for a particular purpose.

RESPONSIBILITIES OF OTHERS

It is the responsibility of the installer or building contractor, acting on behalf of the user, to inspect the unit prior to installation. They are responsible for ensuring that the unit is free from defects or damage.

Notices are placed on and within the unit, as well as on the shipping carton, to inform the installer of their responsibility.

If a problem is identified, the unit must not be installed. DeerValley is not responsible for failures or damage that could have been identified, repaired, or prevented through proper inspection and testing prior to installation.

Damage occurring during transit is the responsibility of the carrier. The user or installer must open the crate and inspect the unit for damage upon delivery. If damage is discovered, it must be reported immediately to the seller and the carrier in writing, and an inspection must be requested. If the carrier fails to respond, the issue should be reported to both the seller and the carrier. Freight claims should be filed promptly thereafter.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover negligence, misuse, abuse, improper installation, carelessness, accidents, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages resulting from improper maintenance, alteration of the product, or failure to follow the care or installation instructions provided with your product. The warranty becomes void if the DeerValley product is altered or if repairs are attempted using unauthorized accessories or parts not provided by DeerValley.

DeerValley is not liable for the loss of use of its products, inconvenience, or any other incidental or consequential costs, expenses, or damages. Please note that some states do not allow the exclusion or limitation of incidental damages.

DISCLAIMER

Except as expressly stated, no warranties or obligations, whether express, implied, oral, or statutory, are provided. No dealer or other individual has the authority to make any warranties or representations regarding DeerValley or its products. DeerValley shall not be held responsible for any such unauthorized warranties or representations.

WARRANTY SERVICE

NOTE: When requesting warranty service, please ensure you have the following:

- A copy of the original invoice
- Date of installation
- Description and pictures of the defect
- Model number or product description

To obtain warranty service or replacement parts, contact DeerValley Customer Service. DeerValley will determine whether to repair or replace the product, issue a refund, or provide a credit.