


ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools




+ Suggested Adults




+ Parts Included

- ① Seat frame (1 pc)



- ② Legs (3 pcs)



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION


- Do not** assemble the product if the parts arrived damaged.
- Do not** assemble if Hardware parts are missing.

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included


- A. Bolt
Ø8x35mm (12 pcs)




- B. Spring Washer
Ø8xØ13mm (12 pcs)



- C. Flat Washer
Ø8xØ19mm (12 pcs)




- D. Allen Key (1 pc)



ASSEMBLY INSTRUCTIONS

①



②

