


MEDICINE CABINET

Instruction Manual






Timeless

BEFORE YOU BEGIN

- Please read these instructions carefully before installation. Familiarize yourself with the necessary tools, materials, and procedures. Retain this manual for future reference.
- All information in these instructions is based upon latest product information available at the time of publication. Imgflx reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.

PACKING LIST

No.	Size		
		24 x 40 "	
(1)		Short Screw M4x6	3 Pcs
(2)		Door Bumper	3 Pcs
(3)		Long Screw Ø5*55	6 Pcs
(4)		Anchor Ø8*50	6 Pcs
(5)		Hinge Cover	2 Pcs
(6)		Bottom Bracket	2 Pcs
(7)		Top Bracket	1 Pcs

- Carefully review all parts and read the installation instructions before you start. if parts are missing, please contact us.

SPECIFICATIONS

Dimension (Inch)	Dimension (Millimeter)	Types of Medicine Cabinet
24 x 40 x 5 1/16	610 x 1016 x 128	Single-door

INSTALLATION INSTRUCTIONS

- Please read all instructions carefully and keep them for future reference.
- Do not discard any packaging materials or instructions until installation is complete and everything has been verified.

IMPORTANT

To prevent damage, do not place the cabinet directly on tile or concrete surfaces prior to installation. Use a protective layer to avoid chipping the corners.

Be sure to check for any hidden wiring or pipes before drilling guide holes to avoid potential damage.

MAINTENANCE

Wipe clean with a soft damp cloth. Apply glass cleaner to cloth and do not apply directly to mirror.

Please avoid harsh, corrosive and abrasive cleaners.






Keep dry and avoid damp environments.

INSTALLATION

Please refer to below surface mount or recessed mount method.

INSTALLATION





Installation Tools (Tools Not Included)



SURFACE MOUNT

Step 1

Refer to hole spacing diagram as below or mark hole position by top bracket(7). then drill holes in the wall by an electric drill.





Product size	
	24"x40"
Distance	
A→B	8"
B→C	8"
C→D	
D→E	
E→F	
F→G	
Interval H	39 3/16"
a→b	16"

SURFACE MOUNT

Step 2

Place anchor(4) into the drilled holes and fix the top bracket(7) by long screw (3).

(3)		Long Screw Ø5x55
(4)		Anchor Ø8x50
(7)		Top Bracket




Step 3

① Lift the cabinet above the top bracket(7). Press it firmly against the wall, then lower it into place on the bracket.

② Secure the bottom bracket(6) to the cabinet using the short screw(1), Do not overtighten.

③ Install the bottom bracket(6) onto the wall with the long screw(3), then fully tighten the short screw(1) to secure the cabinet in place.

(1)		Short Screw M4x6
(3)		Long Screw Ø5x55
(6)		Bottom Bracket





SURFACE MOUNT

Step 4


Snap hinge cover (5) onto each hinge, ensuring they are fully secured.
Stick the door bumper (2) onto the inside of the cabinet door(s).

(5)		Hinge Cover
(2)		Door Bumper



Step 5

The cabinet is now ready for regular use.




RECESSED MOUNT

Step 1


For recessed mount installation, cut openings according to dimensional data in the diagram below.

Dimension Size	W	H	D
24" x 40"	23 3/8"	39 3/8"	4 1/8"



Step 2

Loosen screws on both sides and remove the side panel.




RECESSED MOUNT

Step 3

Carefully place the cabinet into the prepared wall opening. Secure it using the long screws (3) through the side brackets.



(3)		Long Screw Ø5x55
-----	---	---------------------



Step 4

Snap hinge cover (5) onto each hinge, ensuring they are fully secured. Stick the door bumper (2) onto the inside of the cabinet door(s).


(5)		Hinge Cover
(2)		Door Bumper



RECESSED MOUNT


Step 5

The cabinet is now ready for regular use.




HOW TO ADJUST THE HEIGHT OF TEMPERED GLASS SHELF

Loosen the screw on each clamp, slide them along the groove to adjust the shelf to your desired height. Ensure that both clamps are aligned at the same level before retightening.




HOW TO ADJUST HYDRAULIC HINGES



A: Adjusts the door depth

Rotate screw A clockwise or counterclockwise to adjust the door depth and modify the gap between the door and the cabinet frame.



B: Adjusts the door side-to-side alignment

Rotate screw B clockwise or counterclockwise to move the door left or right for proper side-to-side alignment.

Use and Maintenance:

The interior is constructed of mirrored glass and aluminum. Use only a damp cloth to clean. Ammonia or vinegarbased cleansers can damage mirrors.

When cleaning, spray the cloth, not the mirror, or surrounding surfaces, Do not use abrasive cleansers on any parts of the light fixture. Clean mirror weekly with soft damp cloth. Avoid direct water spray. Ensure ventilation if installed in humid environment.

Limited Warranty Two Years Term

We warrant to the original purchaser that our products are free from significant defects in material and workmanship for a period of two (2) years from the date of delivery. We will, at our discretion, repair, replace, or adjust any products found to have significant defects, provided that the defects are reported to us in writing within the warranty period. Installation costs are not covered by this warranty. This warranty is void if the product is damaged during transportation, or if damage or failure is caused by abuse, misuse, abnormal usage, faulty installation, damage in an accident, improper maintenance, or any repairs other than those authorized by us.

At the end of the two-year warranty period, we shall have no further obligation under any warranty, expressed or implied, including the implied warranty of merchantability. We shall not be liable for any consequential damages arising out of or in connection with the use or performance of our products.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Any liability against us under any implied warranty, including the warranty of merchantability, is expressly limited to the terms of this warranty.

To make a claim under this warranty, permission must be obtained from us, and the product must be returned prepaid by the purchaser. Claims under this warranty should be sent directly to the dealer where the product was purchased.

ALL RIGHTS RESERVED

