
ASSEMBLY INSTRUCTION

WF313025


WF313030


WF313031




PARTS LIST - WF313025 B \bigcirc (CR) (CL)0 Quantity: Quantity: Quantity: Quantity: 1 pc 1 pc 2 pcs 1 pc E \bigcirc (D) Quantity: Quantity: Quantity: Quantity: 2 pcs 1 pc 1 pc 1 pc

PARTS LIST - WF313030










HARDWARE LIST


1	2	3	4	5	6	7	8	9
				S				
Allen key Quantity: 1 pc	6x30mm Quantity: 49 pcs + extra 3pcs	6x16mm Quantity: 39 pcs + extra 3pcs	8x30mm Quantity: 16 pcs + extra 2pcs	4x30mm Quantity: 6 pcs + extra 1pc	3x15mm Quantity: 46 pcs + extra 3pcs	Led light Quantity: 1 pc	Screwdrivers Quantity: 1 pc	15x20mm Quantity: 6 pcs
10	(11)							
0								
20x80mm Quantity: 2 pcs	4x20mm Quantity: 4 pcs							


COMPONENTS - KEY DIAGRAM WF313025




















COMPONENTS - KEY DIAGRAM WF313030 WF313031

