


Assembly Instruction




MIX

Wood | Supporting
responsible forestry

FSC® C211622




Customer Support: Info.amerlifhome@gmail.com




N	X1	R	X2				
G	X2	H	X4	J	X12	K	X1
G-1 G-2 Ø4x20mm		H-1 H-2 H-3		J Ø2.5x12mm		K	
A	X12	B	X12	C	X8	D	X5
A Ø6x35mm		B Ø15x10mm		C Ø6x30mm		D Ø4x35mm	
L	X2	M	X18	E	X24	F	X4
L		M Ø4x12mm		E Ø3.5x14mm		F Ø4x10mm	


1





2





3




A	X4	K	X1	M	X2
  					

4




B	X4	C	X4
 			

5




M	X16

6




C	X4	D	X4





7




J	X12
	


8





- 
- 
- 
- 


D	X1	N	X1
			

9




E	X8	G	X1	L	X1	R	X1
		 G-1	 G-2				



10




E	X2
	

11




E	X8	G	X1	L	X1	R	X1
		 G-1	 G-2				

12



E	X2
	

13



14

