
ASSEMBLY INSTRUCTION

Dining Chair



Please read these instructions fully before starting assembly：

1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.

2. Kindly follow the assembly instructions step by step.


3. Do not tighten all screws and bolts until the table is fully assembled.

4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.

5. Parts of the assembly will be easier with 2 people.


Care and maintenance：

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners


A
B
C
C


Part List

A



BACK CHAIR (1pc)

B








SEAT CUSHION (1pc)

C




FRONT LEGS (2pcs)

Hardware List


1  Ø1/4"*L75mm	2  Ø1/4"*L38mm
BOLT (4pcs)	BOLT (2pcs)
3  Ø1/4"*13mm	4  Ø1/4"*19mm
LOCK WASHER (10pcs)	FLAT WASHER (10pcs)
5  5mm	6  Ø1/4"*L60mm
ALLEN KEY (1pc)	BOLT (4pcs)

STEP 1:



BOLT Ø5/16"*75mm	BOLT Ø5/16"*45mm	LOCK WASHER Ø5/16"*13mm	FLAT WASHER Ø5/16"*19mm	ALLEN KEY 5mm
① x 4	② x 2	③ x 6	④ x 6	⑤ x 1

STEP 2:



BOLT Ø5/16"*45mm	LOCK WASHER Ø5/16"*13mm	FLAT WASHER Ø5/16"*19mm	ALLEN KEY 5mm
⑥ x 4	③ x 4	④ x 4	⑤ x 1

COMPLETE

