




Water Slide Instruction Sheet

Product Overview


Contents Include

- 1x Slide
- 3x Boogie Boards
- 2x Repair Patches
- 6x Lawn Anchors




Caution! Children use must be under adult supervision. Do not use on pavement or any hard surfaces. only. Use on flat lawn only. Lawn should be free of any other sharp or hard objects. Proper assembly by an adult is required. Do not dive head-first as this may result in serious injury. Allow a safe distance between sliders. Do not wear glasses or loose jewelry when using. Do not use for longer than 8 hours or damage to lawn may occur. Check anchors occasionally to ensure they are secure. Not for adult use. Not for children under 5 or over 12 years old. Must be under 110lbs/50kg and 5ft/1.5m tall to use.

How To Set Up Water Slide




1. Unroll Slide

Roll out the side, place in desired location, with the bumper side up.




2. Secure the Slide

Using the 6 provided lawn anchors, secure the slide with the 6 anchor straps.




3. Prepare Slide

Using a hose, spray entire length of slide before use to prevent resistance.




4. Connect Water

Attach water hose to port on slide, while water is off. Turn water on to start sprinklers.




5. Adjust Sprinkler Spray

Maneuver the spray side of the slide as desired to adjust the spray direction.




6. Adjust Water Pressure

Using your hose, adjust the flow and pressure of water to your preference.



7. Before Use

Inflate 3 provided boogie boards. Using these to slide will prevent friction



8. Sliding Safely

Use boogie boards under chest and arms with head lifted to slide. Do not dive.