


INSTRUCTION MANUAL




PRE-ASSEMBLY INFORMATION

1. Open the vacuum packaging last until you confirmed the frame suits your space, otherwise, please don't open them which will cause the item unreturnable.
2. This sofa ships in 2 boxes, we recommend unpacking and starting assembly when 2 boxes are received.
3. Our cushions are vacuum packed for convenient shipping. Please allow 2-3 days for them to fully expand to their original shape and for any wrinkles to disappear.

NOTICE

- Please keep this manual and hand it over when you transfer the product.
- Please read the following instructions carefully and use the product accordingly.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.
- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Please assemble the item in a spacious room and do not place the unwrapped product directly on the ground to avoid damage.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (films, plastic bags and foam, etc.) away from children and pets.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Do not expose product to direct sunlight exposure or rain, and do not put it in a humid place. Failure to do so may accelerate the distortion or discoloration.



TWO PERSON ASSEMBLY



UP TO 30 MINUTES
FOR ASSEMBLY




WEIGHT LIMITATION
580LBS


IMPORTANT

1. We recommend open the vacuum sealed cushions and pillows after the sofa frame is installed.
2. Remember to remove the parts packed under the bottom of seat frame.
3. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
4. Do not over tighten screws and bolts to avoid stripping.
5. Please use hand tools to assemble this product. If you're using power tools, remember to set the tool to low torque to avoid damage.












The following is the list of components contained in each box.









CHAISE







Main structure accessories




Hardware parts




Structural accessories




STEP 1



STEP 2




STEP 3



Loosen the screws at first for better engagement.




STEP 4



Loosen the screws at first for better engagement.




STEP 5



Adjust the screw to make the side panel and back panel vertical to facilitate subsequent installation.


STEP 6



b  x4

g 


STEP 7



a  x4

g 

STEP 8




c  x6


g 

Installation is easier after tilting.

STEP 9




STEP 10












Dangerous

The top panel might bounce and cause injury before assembling the seat cushion, please be careful during assembling.

TWO SEATS




Main structure accessories



Structural accessories

D-4 Sofa leg



x4

D-5 Connector




Lx1




Rx1

D-8 Roller




Lx1



Rx1

Hardware parts


a Bolt



M6*20

x8


b Bolt



M6*40


x5

d Washer



x4

e Bolt



M6*20

x4

f Washer




x5

i Washer




x9


STEP 1




STEP 2




STEP 3



STEP 4




STEP 5



Loosen the screws at first for better engagement.



STEP 6




a (screw) x4


i (hinge) x4

g (screw)


STEP 7





STEP 8




Pull-out Sofa








Hardware parts




Structural accessories




Main structure accessories



STEP 1




STEP 2




Tie the drawstring and use it to pull the drawers open and lift the supporting frame.


STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8



STEP 1




STEP 2




 If the back frame gap is too large, adjust the screw to reduce the gap.

STEP 3








Lift it slightly and place it on the track.

STEP 4



STEP 5





RETURN POLICY

Thank you for purchasing our product. We do our best to ensure your furniture arrives without any problems, but occasionally mistakes happen—as humans we are imperfect beings. In the event that a part is damaged or missing, we will be more than happy to provide you with replacement part(s) for free. Please contact us via email or website. All your concerns will be taken good care of by our CUSTOMER SERVICE TEAM. All items can be returned for any reason within 60 days of the receipt and will receive a refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. Once a returned item has been received, refunds or replacements will be processed within 5 business days. All returns must be shipped back in original boxes and shipped back to Return Center at the customer's expense. Pictures may be required for some returns to ensure an item is not damaged prior to its return. If the reason for return is a result of an error by us, then a pre-paid shipping label will be provided via email. New boxes for return will not be provided, and need to use the original shipping boxes. Items received without original boxes may not be accepted or may increase your return processing time.



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.