


Installation & Assembly






A	64PCS
	Ø6*35mm

B	64PCS
	Ø15*10mm


C	28PCS
	Ø8*30mm

D	28PCS
	M3.5*14mm

E	2PCS
	M4*12mm


F	1PC
	

G	4PCS
	


H	4PCS
	

I	4PCS
	

J	2PCS
	


K	8PCS
	M6*35mm

1




2PCS

2




2PCS

3




2PCS

4




1PC

5




4PCS

6




2PCS

7




2PCS

8




2PCS

9




1PC

10




2PCS

11




1PC

12



1PC


13




2PCS


"A"Hardware installation example

1





Loosen the screw outward to create more space for the plastic particles to contract, allowing them to be inserted into the holes.






After separating the screw from the plastic particle, first press the plastic particle into the hole, then tighten the screw back in.








Step1

A	64PCS



Ø6*35mm

C	28PCS



Ø8*30mm

Ax2
x2

1

10

Ax2
Cx2
x2

6

Ax4
x2

Ax22
Cx4
x1

4

4

Ax10
Cx4
x1


12

5

Ax4
Cx4
x4


Step2

B	4PCS
	
Ø15*10mm	







Step3

B	12PCS
	
Ø15*10mm	



Step4


G	4PCS	F	1PCS	H	4PCS	D	28PCS
							
							M3.5*14mm



K	8PCS	I	4PCS
M6*35mm			

Step5

B	4PCS
	
Ø15*10mm	




Step6

B	18PCS




Ø15*10mm

Step7




Step8



B	8PCS

Ø15*10mm

Step9



E	2PCS



M4*12mm

J	2PCS



Step10

B	18PCS



Ø15*10mm

Set aside all surplus accessories as spares.

OK