

Installation & Assembly

1.

2.

3.

Ax1	Bx1	Cx1	Dx1
Ex2 	Fx6 	Gx1 	Hx2
Ix1 			

A		1PC	E		8PCS
B		1PC	F		1PC
C		4PCS			
D		8PCS			