

USER MANUAL

4 DOOR WARDROBE WITH MIRROR


TOOLS REQUIRED




Phillips screwdriver
(Not included)



Hammer
(Not included)



Drill
(Not included)



Protective blanket
(Not included)



ATTENTION


Keep children and pets away while assembling.




How to use cam locks

CAM LOCK FASTENING SYSTEM


This Cam Lock Fastening System will be used throughout the assembly process.




1




2




3



4







EN

INTRODUCTION

Thank you for choosing our products. Please read the instructions carefully and keep them for future reference. If you need further assistance, please contact our customer service online via email.


PRECAUTIONS


1. When installing the product, use a soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence.
5. The structure of this product can not meet the requirements of the placement of heavy items and children climbing.

WARRANTY

We provides an **18 Month** Warranty on all products starting from the date of original purchase. If the product has any manufacturing defect, please contact customer service via email with your order number and other details to the problem. We will send you further information about the return or exchange.


PACKAGE CONTAINS




28
29
28
28
28
21
23
26
19
24
22
24
x2
25
21
27
20
22
x2
25
21
27
22
18
x2


HARDWARES LIST

A x94




M6*40mm

B x94




M15*11mm

C x40




M8*40mm

D x178




M3.5*14mm

E x6



F x82




M5*40mm


G x1



H x50




J x12




12inches

K x15




L x16



M x4




N x2



M8*60mm

O x52



M3*12mm

P x12



Q x8




M4*10mm

R x4




M4*20mm

S x6




T x6



U x1




V x36




M3*16mm

W x1



5V/2A

X x1



Y x2



















Z x2


















PARTS LIST » A BOX

Unit: (mm)

① x1  1207*500*12 mm	② x3  1156*500*15 mm	⑦ x2  784*70*15 mm
⑧ x1  784*70*15 mm	⑩ x1  1207*500*15 mm	⑭ x1  792*467*3 mm
⑮ x1  1207*500*15 mm	⑱ x2  397*238*15 mm	⑲ x2  797*238*15 mm
㉘ x3  1175*397*15 mm	㉙ x1  1175*397*15mm	㉚ x2  377*70*15 mm
㉛ x1  1156*500*15 mm	㊳ x1  377*70*15 mm	㊴ x2  792*481*3 mm
㊵ x1  377*70*15 mm		









PARTS LIST » B BOX

Unit: (mm)

③ x1  1156*500*15 mm	④ x1  1156*500*15 mm	⑤ x2  377*465*12 mm
⑥ x1  1024*385*3 mm	⑪ x1  459*500**15 mm	⑫ x1  459*500*15 mm
⑬ x1  459*500*15 mm	⑯ x4  438*118*15 mm	⑰ x2  770*118*15 mm
⑳ x2  238*397*15 mm	㉑ x6  320*120*12 mm	㉒ x6  320*120*12 mm
㉓ x2  736*120*12 mm	㉔ x4  307*60*12 mm	㉕ x4  329*120*12 mm

PARTS LIST » B BOX

Unit: (mm)


26 x2  744*315*3 mm	27 x4  337*315*3 mm	32 x1  459*500*15 mm
33 x2  467*385*3 mm	34 x1  393*500*12 mm	35 x1  393*500*15 mm
36 x1  393*500*15 mm	37 x2  770*115*15 mm	


INSTALLATION INSTRUCTION


J x12pcs




12 inches








The Damping



J1



J2

01

C x6pcs



M8*40mm

D x12pcs





M3.5*14mm


J1 x4pcs



12inches







02

C x4pcs



M8*40mm

D x12pcs





M3.5*14mm

J1 x4pcs



12inches





03

C x4pcs



M8*40mm

D x12pcs





M3.5*14mm


J1 x4pcs




12inches









04

A x2pcs




M6*40mm

C x2pcs



M8*40mm




05

B x2pcs



M15*11mm



06


D x16pcs



M3.5*14mm


E x2pcs





07

G x1pc



08


D x30pcs



M3.5*14mm

K x15pcs






09

A x16pcs



M6*40mm



x2

10

B x16pcs




M15*11mm

C x4pcs




M8*40mm




x2

11

F x16pcs



M5*40mm



12

D x16pcs




M3.5*14mm


E x2pcs



L x16pcs









13

F x4pcs



M5*40mm



14

A x4pcs





M6*40mm

B x4pcs




M15*11mm





15



16

A x8pcs



M6*40mm

B x6pcs





M15*11mm

C x2pcs



M8*40mm





17

B x2pcs




M15*11mm

F x2pcs





M5*40mm

N x2pcs



M8*60mm






18

A x12pcs



M6*40mm




19

B x6pcs



M15*11mm




20

B x2pcs



M15*11mm




21

B x6pcs



M15*11mm



22

C x4pcs



M8*40mm


D x2pcs



M3.5*14mm

M x1pc






23

A x11pcs



M6*40mm




24

B x4pcs



M15*11mm



25

C x2pcs



M8*40mm


D x6pcs




M3.5*14mm

M x3pcs









26

F x2pcs



M5*40mm




27

B x2pcs



M15*11mm




28

B x2pcs



M15*11mm




29

F x2pcs



M5*40mm




30

B x3pcs



M15*11mm




31


F x4pcs



M5*40mm



32




33


F x4pcs



M5*40mm




34




35


F x8pcs



M5*40mm



36




37

F x4pcs



M5*40mm




38

C x8pcs



M8*40mm



39

A x9pcs




M6*40mm

C x4pcs



M8*40mm




40


B x9pcs



M15*11mm



41



42

O x16pcs



M3*12mm


E x2pcs



F x4pcs



M5*40mm




43

Z x2pcs

Z1


Z2

Z3




44

F x16pcs




M5*40mm



x2

45




x2

46

A x16pcs



M6*40mm




x2

47

B x16pcs



M15*11mm



x2

48


P x4pcs



Q x4pcs



M4*10mm



x2

49

O x12pcs





M3*12mm

J2 x4pcs



12inches







x2

50

F x16pcs




M5*40mm



x4

51



x4


52

A x16pcs



M6*40mm

x2




x2

53


B x16pcs



M15*11mm



x2



x2

54


P x4pcs



Q x4pcs



M4*10mm



55

O x24pcs




M3*12mm


J2 x4pcs



12inches




56



57

U x1pc



58

D x12pcs



M3.5*14mm

P x2pcs




R x2pcs





M4*20mm

S x6pcs











59

D x24pcs



M3.5*14mm





60

D x12pcs



M3.5*14mm

P x2pcs




R x2pcs





M4*20mm

T x6pcs












61

D x24pcs



M3.5*14mm







The ways to adjust the door


- ► Before adjusting the hinge, please check whether the cabinet is skewed.
- ► If the skew can not be repaired, adjust the cabinet to vertical position.
- ► Please adjust the hinge with the door open.

Obvious gaps between doors or Doors don't look closed




1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.






*** If the 2 doors are overlap, please turn the "internal & external screw" to the left.**

When door is crooked




1 Rotate the "front and rear screws to the left.




*After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right Slightly.


2 Push the door to the cabinet.




3 Rotate the "front and rear screws to the right.




When door is leaning




Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the upside




Tum "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




1 Tum "up & down screw" to the left.



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right.



***If the door is lower on bottom, please lift up the left door slightly on step 2.**


62

V x36pcs

V1

V2

M3*16mm




63


W x1pc




5V/2A

X x1pc








64

H x50pcs



65

Mandatory!

Y x2pcs



For safety reasons, we strongly recommend you follow these instructions to install the anti-tipping hardware, when installed properly, this hardware may prevent the unit from tipping unexpectedly.


⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER open more than one drawer at a time.
- NEVER put a TV on this product.
- Place heaviest items in the lowest drawers.
- NEVER allow children to stand, climb or hang on any drawers,doors, or shelves.

This is a permanent label. Do not remove!




66

Y x2pcs

Y4

Y5



⚠WARNING

INGESTION HAZARD: This product contains a button cell or coin battery.
DEATH or serious injury car occur if ingested.
A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
KEEP new and used batteries **OUT OF REACH of CHILDREN**
Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- This product contains a CR2025,DC3V coin battery. A coin battery can cause serious internal chemical burns if swallowed.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 132°F (60°C) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.