
ASSEMBLY INSTRUCTION


PATIO CONVERSATION SETS




Notice:

1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. Note : If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.


x1




x2



x2




x1



Part List and Hardware

A x 1



Wooden Top

B x 2






Table Leg

C x 2




Stool Seat

D x 4




Stool Leg

E x 3




Left Chair Armrest

F x 3




Right Chair Armrest

G x 2




Chair Seat

H x 2




Chair Back

I x 1




Bench-3 Seat 1

J x 1




Bench-3 Seat 2

K x 1




Bench-3 Seat 3

N x 1




Bench-3 Back

L x 1




Supporting Leg

Q x 1




Connector Bench

O x 2




Stool Seat Cushion

P x 5



Chair Seat Cushion


M x 5



Chair Back Cushion (5 pcs)


Part List and Hardware

1 x 8




Extra (1 pc)
Bolt M6x15

2 x 24




Extra (2 pcs)
Bolt M6x30

3 x 32




Extra (2 pcs)
Bolt M6x35

4 x 6




Extra (1 pc)
Bolt M6x45

5 x 6




Extra (1 pc)
Bolt M6x60

6 x 76




Extra (3 pcs)
Flat Washer M6

7 x 6




Extra (1 pc)
Flat Washer M6

8 x 2



Allen Key


9 x 1



Key

CARTON CONTENT:


E x2




F x2




G x2




M x1






Hardware

A x1




B x2




H x2




P x2




M x1




N x1



Q x1




P x2




D x4



C x2




E x1




F x1




I x1



J x1




K x1




L x1




M x3



P x1



O x2





STEP 1

A x1


B x2






② x 8	⑥ x 8
	
M6*30 mm	M6x16x1mm

STEP 2








STEP 3


C x2

D x4









② x 16	⑥ x 16
	
M6*30 mm	M6x16x1mm


x2


STEP 4

O x2











x2

STEP 5







x2


STEP 6

G x2

F x2






③ x 6	⑥ x 6
 M6*35 mm	 M6x16x1mm

x2

STEP 7

H x2




3 x 4	4 x 2	6 x 4
M6*35 mm	M6*45 mm	M6x16x1mm

x2

STEP 8

E x2




3 x 6	4 x 2	6 x 6
M6*35 mm	M6*45 mm	M6x16x1mm


x2

STEP 9

M x2


P x2







x2

STEP 10



STICKY PAD






x2


STEP 11

I x1

J x1


K x1




5 x 6	6 x 12	7 x 6
 M6*60 mm	M6x16x1mm	

STEP 12


Q x1



3 x 4	6 x 4
 M6*35 mm	M6x16x1mm

STEP 13


F x1



③ x 3	⑥ x 3
M6*35 mm	M6x16x1mm

STEP 14


N x1





③ x 6
M6*35 mm
④ x 1
M6*45 mm
⑥ x 6
M6x16x1mm

STEP 15


E x1




3 x 3  M6*35 mm	
4 x 1  M6*45 mm	
6 x 3  M6x16x1mm	

STEP 16

L x1





1 x 8  M6*15 mm	6 x 8  M6x16x1mm

STEP 17

P x3


M x3







STEP 18

STICKY PAD





STEP 19



INSTRUCTIONS FOR USE:

1. Never force the connections. Re-tighten the screws after few days.
2. Keep the Instructions Al leaflet, it contains information when claiming for missing parts.
3. Ensure to not exceed the maximum loading weight for a safe usage. Avoid jumping on or applying excessive pressure to the product to prevent structural damage.
4. Do not move loaded furniture.
5. Wood is a natural material, each piece of wood is unique. It is therefore normal that its appearance shows variations in colour and appearance.
6. Exposed to the sun, the wood will naturally turn gray over time and, in the more or less long term, depending on the exposure conditions, present micro-cracks which will not jeopardize the solidity of the product.

STORAGE AND CLEANING:

1. Outdoor furniture can be cleaned with soap and water. Rinse the furniture with clean water.
2. Always store the dry and clean product at room temperature. If the product becomes wet, allow it to dry thoroughly in a dry, well-ventilated area before using it again.
3. Do not cover hermetically the product, this way locks the humidity and can cause stains and wood deformation.
4. For any specific maintenance or renovation product, check the compatibility of the products you apply with the support to be maintained.
5. Refer to the instructions for use of the maintenance product.
6. Use a furniture cover whenever possible to protect it from the elements and dirt.
7. Clean fabric outdoor furniture using washine machine with gentle cycle.
8. To avoid shrinkage, stretch back over the frame before the fabric is completely dry.
9. If the steel isn’t stainless, wipe it carefully to avoid rust.
10. Keep away from open flames or hot objects to avoid fire hazards.
11. Keep children and pets away from sharp parts of the product to prevent potential injuries