


Electric Fireplace Installation Instructions

Step 1: Arrange crystals and artificial firewood (combine them according to your preference).



Step 2: Install the front tempered glass panel. Align the tempered glass with the groove along the bottom edge and insert it.



Step 3: Install the tempered glass pressure strip. Before installation, align the screw holes first.



Step 4: Tighten the 4 screws on the pressure strip to complete the installation of the front tempered glass panel.



Step 5: Install the metal brackets on both sides. (Install the short-side metal brackets) Use the flat-head screws provided in the kit and screw them in.



Step 6: Install the metal brackets on both sides. (Install the long-side metal brackets) Use the flat-head screws provided in the kit and screw them in.



Step 7: Finished Installation of one side metal bracket, as shown in the figure below. (Side metal brackets installation is optional.)



Step 8: The fireplace installation is complete, as shown below.



If you need to embed the unit into a wall for installation, please follow these steps.

Step 1: Remove the metal covers. Before installing the fireplace into the wall, remove the 2 side metal cover panels we placed behind the fireplace. (As shown in the figure below.)



Step 2: Install the side metal panels removed from the back of the fireplace onto the side of the fireplace.



Step 3: Install the metal mantel bracket (The mantel bracket set includes four pieces, which can be installed selectively.). Tighten the countersunk screws with a Phillips screwdriver.



Step 4: Finished installation view of the side metal panels and mantel mounting bracket.



1. If the electric fireplace fails to operate normally, press the reset button at the top of the control panel. Then hold down the power button on the fireplace until the indicator light illuminates to resume operation.
2. If any questions, please feel free to contact us at email: support@hiresc.com, we will respond to you within 24 hours.