


Assembly Instructions



Wood Shelf




Contact Us

We're here to help you.

Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.




We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.
























⚠ Caution




Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List

①  1pc	②  1pc	③  1pc	④  6pcs
⑤  1pc	⑥  1pc	⑦  1pc	⑧  1pc
⑨  1pc	⑩  1pc	⑪  1pc	⑫  1pc
⑬  1pc	⑭  1pc	⑮  1pc	⑯  1pc



Hardware List

Ax40	Bx40	Cx32	Dx16	Ex18	Fx24
 6*35	 15*10	 6*30	 5*40	 3.5*14	 4*35



Gx4	Hx2	Ix2	Jx1	Kx16	Lx2
 6*50	 	 	 	 	 4*40

Mx48



1



2





3




Cx12	Bx12
 6*30	 15*12

4





Jx1	Cx4	Dx4
	 6*30	 7*40

5





6





Gx4	Jx1	Dx8
		
6*50		5*40


7



8




9



Fx12



4*35

10




Cx12	Bx12
	
6*30	15*10


11



12






13






Jx1	Cx4	Dx4
	 6*30	 5*40

14



Mx48	Kx16	Ex16	Bx12
		 3.5*14	 15*10

15



Ex2	Hx2	lx2	Lx2
 3.5*14			 4*40

