



ADJUST THE DOOR GAP BY ADJUSTING THE HINGES



The gap between the doors is large




Turn the screw C clockwise



There is a gap between the door and the upper or lower




Step 1:
Loosen screws A and B, then adjust the height of the door until it reaches the appropriate position.
Step 2:
Re-tighten the screw to fix the doors.



Cabinet doors are overlapping or not in the correct position



Turn the screw C counter-clockwise



The gap between the door and the cabinet is too wide or too tight.



Step 1:
Loosen screw D and push or pull the door to the appropriate position.
Step 2:
Re-tighten the screw to fix the doors