









CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Back		1x
B	Seat		1x
C	Right side		1x
D	Left side		1x
E 1	Allen Bolt	 M6 x 70	8x
E 2	Allen Screw	 M6 x 60	5x
E 3	Extra Bolt	 M6 x 50	1x
E 4	Allen Key		1x

Product Dimension: 38.98"W x 72.83"D x 26.77"H

Weight capacity : 600 lbs.

Warning : Do not stand on the bench

Warning : Do not torque bolts / screws

