








Introduction

Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Package includes

NO	Description		QTY
A	Shade		1
B	Top and middle tube		6
C	Bottom tube		3
D	Holder		1
E	Lock ring		1
F	Reflex housing		1

Product Size




Specification

Product Name	Floor Lamp
Max Wattage	60 W
Bulb Base	E26
Number of bulbs required	1
Product Size	L22.8 x W21.3 x H63"
Product Material	Metal
Base Material	Metal
Switch Type	Foot Switch on/off


Assembly Instructions

1. Twist the top iron pipe (B) and the tripod head (A) to tighten. Then Twist the middle pipe (B) with top pipe. Finally twist the bottom iron pipes (C) and B to the pipes in turn to tighten.


Please make sure the two parts of the iron pipe fit. There should be no gap between them so that they remain stable.



2. Install the bulb holder (D) on the lampshade. Then install the lock ring (E) on the holder.



3. Screw the bulb (E26 Base) onto the lamp cap (Bulb sold separately).



4. Install the reflex housing (F) on the holder.

