



Assembly Guide




READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL


Ax1




Bx1




Cx1




Dx1




Ex1




Fx1




Gx1




Hx1




Ix2




Jx1




Kx1




Lx1




Mx1




Nx1




Ox2




Px1



Qx2




Rx1




Sx1



Tx4




Ux4



Vx2




①x16+1




M3*12mm

②x24+2




M3*16mm

③x16+1




M3.5*20mm

④x16+1



M3.5*25mm

⑤x4



M3.5*30mm

⑥x36+2




M3.5*35mm

⑦x8+1




M3.5*50mm

⑧x4




M6*30mm

⑨x8+1




M6*45mm

⑩x2



M8*35mm


⑪x26+2




wood stick

φ8*20mm


⑫x4




⑬x4




⑭x2




⑮x2




⑯x2



⑰x1



⑱x1



Ax1


Bx1

Cx1

Dx1

⑦x4

⑪x4



Ex1


Fx1

Gx1


Hx1

⑦x4

⑪x22



⑥x12




Ix2

Vx2



②x24

⑧x4


⑫x4




Tx4
⑨x8




Kx1
Lx1
④x8





Px1
Qx2
Rx1
④x8



⑥x4





⑥x12**⑥x6****⑥x6****Ux4****⑥x8**

③x16


⑮x2

⑯x2

③x4



③x4



Mx1


Nx1

Ox2


M

N


O








Sx1
⑩x2



Jx1
①x16
⑤x4
⑬x4



14x2

⑪x1

⑫x1

