


Assembly Instructions

TV Stand






Contact Us

We're here to help you.


Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.

Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.






We recommend using hand tools for assembly.
If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.


















⚠ Caution





Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.




Parts List

1  1 pc	2  1 pc	3  2 pcs	4  1 pc	5  1 pc
6  1 pc	7  1 pc	8  1 pc	9  4 pcs	10  2 pcs

Hardware List


A	B	C	D	E	F
					
Ø6x40mm	Ø15x12mm	Ø8x30mm	Ø7x47mm	Ø6x40mm	M8x35mm
28 pcs	32 pcs	32 pcs	6 pcs	4 pcs	4 pcs

G	H	I	J	K	L
					
M6x30mm	Ø22x26mm	M4x12mm	M6xØ23mm	Ø21mm	M4
1 pc	2 pcs	2 pcs	5 pcs	24 pcs	1 pc


M	N	O	P
			
M5	M8x17mm	Ø3.5x14mm	
1 pc	4 pcs	12 pcs	2 pcs

Installation of Cams and Pins



Step 1-2: Align the plastic part with the mounting hole and press it in. If you can't press it in, loosen the screw counter clockwise or completely remove the screw from the plastic part and try again.
Step 3-4: After pressing the plastic part into place, use a screwdriver to tighten the screw clockwise.



Screw the pin into the hole. Set the cams correctly by aligning the head of the cams with the lock pins. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.





1




E

Ø6x40mm
2 pcs


2



B	C
	
Ø15x12mm	Ø8x30mm
2 pcs	2 pcs




3




E



Ø6x40mm
2 pcs




4






B	C
	
Ø15x12mm	Ø8x30mm
2 pcs	2 pcs




5





D	L
	
Ø7x47mm	M4
6 pcs	1 pc



6





A

Ø6x40mm
8 pcs




x2


7




8





J	N	O
		
M6xØ23mm	M8x17mm	Ø3.5x14mm
5 pcs	4 pcs	12 pcs



9




F	M
	
M8x35mm	M5
4 pcs	1 pc





G


M6x30mm
1 pc



11




A

Ø6x40mm
10 pcs




12

B	C
	
Ø15x12mm	Ø8x30mm
6 pcs	10 pcs




13




B

Ø15x12mm
4 pcs


14




H	I
	
Ø22x26mm	M4x12mm
2 pcs	2 pcs




15





16



17




A

Ø6x40mm
10 pcs




18

B	C
	
Ø15x12mm	Ø8x30mm
6 pcs	10 pcs




19



B


Ø15x12mm
4 pcs

20






K

Ø21mm
24 pcs



21



When it is not level on the ground, please adjust here

Thank you for your support!

