

# PLEASE DO NOT RETURN TO STORE



#### Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

## **Before Installation**

#### Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

• We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.


• Please do not over tighten screws or bolts until the assembly is completed.


• Keep children and animal away from the work area, small parts could choke if swallowed.


• Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.




#### **Cam Lock Assembly Instructions**











A	В		С	
ø6x35mm	ø14.5x12mm		ø8xø4x25mm	
Three in one bolts(36pcs)	Three in one lock(36pcs)		Round head screw(4pcs)	
D	Ε		F	
		$\sim$		
ø8xø4x32mm		40		<b>V</b>
Round head screw(24pcs)	Handle(5pcs)			<u>ø5/32"x20mm</u> Handle screw(1pc)
G	н		Ι	
U		T.		6
ø5/32"x25mm		Due Ferte (Ana)		
Handle screw(4pcs)		Duo Forte (1pc)		otary Hinge(2pcs)
J	K	100	L	
Emmun	E C C C C C C C C C C C C C C C C C C C			
ø6xø3x12mm		Ø		ø7xø3.5x15mm
Flat head screw(8pcs)	Damping hinge (2pcs)		FI	at head screw(12pcs)
M	Ν		0	
	Ø/////// ø8x30mm			
			<u>T</u> e	
Laminate pad(4pcs)	Wood dowel(36pcs)		۸	nti fall hardware(1set)
































## HINGE ADJUSTMENTS



## Sideways / Tilt adjustment

Turn the screw

**clockwise** to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet

## **2 4** Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down

### 3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw clockwise to decrease the gap between the door and the cabinet anticlockwise to increase the gap between the

door and the cabinet

