Instruction Manual

Please save this manual for future reference.

Product Name:	4Ft Pre-lit Green Artificial Christmas Potted Tree

Thank you for purchasing this product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

CARTON CONTENTS:

Description	Quantity
Tree Section(A)	1
Tree Pot	1
Battery Box	1


Before You Start

1. Decide on an appropriate location for your product.
   Note: This tree set may utilize light sets that are marked for indoor and outdoor use, but the artificial trees are for indoor display only.
2. Retain the instructions for future use and save the carton for storing your tree.

Assembly and Instruction Procedure (no tools required for assembly):

Remove all packaging (i.e., cardboard or plastic) before beginning. If your artificial tree has snow-flocking, we suggest unpacking the tree on a large cloth. Some of the flocking may come off during unpacking and fluffing of branches.

1. Assemble the Tree: Put the pot base on a flat surface. Carefully insert the Tree Section (A) into the pot. Make sure the tree poles are firmly inserted into the pot. Take care not to place unnecessary pressure on the brackets during assembly.



Instruction Manual

Please save this manual for future reference.

Product Name:	4Ft Pre-lit Green Artificial Christmas Potted Tree


2. Shape the Tree:
   Begin to shape the branches from the bottom of the tree to the top. Start with the tree tips farthest away from the center pole.
   After shaping the tree, step back to look for any gaps. Reshape branches as needed. You can upsweep the branch tips for a uniform look. Once you have the tree the way you want it, you can start decorating!


Fig.1


Fig.2


Fig.3

Battery box button function:



1. Open the battery compartment.
2. Insert 4 AA batteries (not included). Do not mix alkaline, standard, or rechargeable batteries.
3. At the top of the battery box there is a black button that operates the lights (timer, on, and off).
   - Press once to set the timer for the lights (6 hours on; 18 hours off). The cycle will repeat automatically unless the batteries are exhausted.
   - Press twice to set to "On" for lights always on.
   - Press three times to turn the lights off.

USE AND CARE INSTRUCTIONS

1. Before using or reusing, inspect the product carefully. Make sure the battery box is properly covered.
2. 4 AA size batteries are to be used (not included).
3. Insert batteries with the correct polarity in the battery box.
4. After inserting or reusing batteries, make sure to cover the battery box.

Instruction Manual

Please save this manual for future reference.

Product Name:	4Ft Pre-lit Green Artificial Christmas Potted Tree



Warnings:

1. Risk of Fire and Electric Shock – please follow instructions and warnings on string lights.
2. Do not place it near fireplaces, candles, outdoor heaters, or other similar sources of heat. This item is not flame retardant.
3. Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the tree may fall or blow into.
4. Keep wires clear of being pinched or cut during assembly or installation. Do not use wires with cut or pinched insulation.
5. Make sure the final assembly is stable enough to hold the tree upright.
6. Do not use candles on the tree. Use only with the pre-installed string lights included.
7. This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.

Troubleshooting:

1. Lights do not come on: Check that the batteries have been installed correctly.
2. Tree is not straight: Try adjusting the pole to ensure it is securely fitted into the pot. It is better if the tree is in the vertical position when adjusting.
   Note: If these actions do not resolve the issue with the tree, please do not disassemble the tree yet. Please contact customer service for assistance.

Storage:

1. Remove batteries from each of the battery compartments.
2. Remove all decorations (this does NOT include the pre-installed string lights).
3. Remove the trees from the pots. Press the tree tips back up against the pole.
4. Place the trees into the carton or storage container.
5. Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35˚C (95˚F).