













PRODUCT GUIDE AND INSTALLATION MANUAL







Parts List:




Parts List:

							
(H) x1	(I) x1	(J) x1	(K) x1	(L) x1	(M) x1	(N) x2	(R) x2


					
(G) x2	(Z2) x4	(Z3) x2	(Z4) x2	(Z5) x8	(Z7) x22

							
M8x55mm	Ø6xØ18mm	KEY 4	M4x6mm	M6x8mm			
(Y2) x2	(X) x2	(W) x1	(Z6) x8	(Z8) x2			


Step 1




Step 2




Step 3




Step 5




Step 4




Step 6




Step 7




Step 9




Step 8




Step 10




Step 11




Step 13




Step 12




Step 14




Step 15




Step 17




Step 16




Step 18




Step 19




Step 21




Step 20



Step 22



RGB(W) CONTROLLER



NO.	Dynamic modes	NO.	Dynamic modes
1	W+Red	7	3 colors jump
2	W+Green	8	3 colors fade
3	W+Blue	9	7 colors jump
4	W+Yellow	10	7 colors fade
5	W+Purple	11	Full colors fade
6	W+Cyan		