

ASSEMBLY MANUAL


FCN0231_00 FCN1150_00

Model : FCN0251_00

: FCN0690_00


Customer Support: ServiceTeam86@outlook.com

BEFORE YOU START




1. TOOLS REQUIRED

Phillips screwdriver, not included.




2. CHECK ALL PARTS

Make sure all panels and hardware are included before assembly.




3. USE A SOFT SURFACE

Assemble on a carpet or protective mat to avoid scratches.



4. DO NOT FULLY TIGHTEN SCREWS FIRST

Tighten screws only after the unit is fully aligned.



5. Recommended: 2 Adults

Larger panels are easier and safer to assemble with two people.




6. KEEP SMALL PARTS AWAY FROM CHILDREN

Small parts may present a choking hazard.

PRODUCT OVERVIEW

Finished Product & Dimensions






Please review the finished product shape and overall dimensions before assembly.

HARDWARE INSTALLATION TIPS


NOTE:

1.






Ensure there is no gap
after tightening




2.



3.



4.




Assembly Time: 30 Minutes


Assembly Difficulty ★★☆☆☆



Installation of Cams and Pins

Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening to the hole of the pin it is locking. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.




















Read each step carefully before starting. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.


















Parts & Hardware List

 ① 1pc	 ② 1pc	 ③ 1pc	 ④ 1pc
 ⑤ 1pc	 ⑥ 2pcs	 ⑦ 1pc	 ⑧ 1pc
 ⑨ 3pcs	 ⑩ 3pcs	 ⑪ 3pcs	 ⑫ 3pcs
 ⑬ 3pcs	 ⑭ 3pcs	 ⑮ 1pc	 ⑯ 1pc
 ⑰ 1pc			


Parts & Hardware List

 A 38+4pcs	 M5X50MM B 15+2pcs	 C 38+4pcs	 M6X30MM D 12+2pcs
 M3. 5X12MM E 42+4pcs	 F 8+1pcs	 M3X14MM G 8+1pcs	 H 1pc
 I 2pcs		 M3	
 12X300MM CL 3pcs	 12X300MM DL 3pcs	 12X300MM DR 3pcs	 12X300MM CR 3pcs


1




2







3




4






5







6




Align the slots of the two boards to facilitate the installation of the No. 15 backplane.







7





8





9





10






11




12









14




X3





15



16



17



 WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install the provided anti-tip device. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers.
	<i>This is a permanent label. Do not remove!</i>

SAFETY FIRST, STYLE ALWAYS

Thank you for choosing our product. To ensure safe use and optimal performance, please read and follow the instructions below:

- **Assembly:** Carefully follow all assembly instructions and securely tighten all screws and fasteners.
- **Intended Use:** Use the furniture as intended and do not exceed the stated weight limits.
- **Handling:** Move the furniture carefully and inspect it regularly for loose hardware.
- **Tipping Hazard:** Secure the furniture to the wall using the provided anti-tip device. Failure to do so may result in serious injury.
- **Overloading:** Do not exceed the recommended weight limits, as this may result in damage or injury.
- **Sharp Corners:** Use caution around sharp corners, especially in households with children.

MAINTENANCE & CLEANING TIPS

- **Regular Cleaning:** Use a soft, dry cloth to wipe the surface of the cabinet regularly. Avoid harsh chemical cleaners.
- **Protect from Sunlight:** Keep the cabinet out of direct sunlight to prevent damage to the material and finish.

WE'RE HERE TO HELP.

We don't just sell furniture - we're here for the long haul! If you run into any issues due to manufacturing defects or material problems, we offer a 1-year warranty. That means we'll replace any faulty parts for free - no hassle.

Email: ServiceTeam86@outlook.com