


ITEM NO. SBYL1920

Scan for manual,
video & advice.

If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com


MAINTENANCE AND WARNINGS


Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS


Installation:
60 minutes.


Two Person



Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having dificulty with assembly? Missing parts? Please send email with your order number to customerservice@hulalahome.com


For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all 2 boxs (A/B), then begin the assembly !




Exploded Diagram

Please confirm that you have received all 2 boxs (A/B), then begin the assembly !




Parts List *(Canton B)*

C ×1




Left side panel

D ×1




Right side panel

E ×1




Middle panel

F ×1



Left adjustable Shelf

G ×1



Right adjustable Shelf

I ×1




Mid-leg

J ×4




Foots

K ×2



Left door

L ×2



Right door



Hardware Liste *(Canton B)*

1 ×4



Hold hands

2 ×4



Screw
Ø4*25mm

3 ×30+3



Screw
Ø3*15mm

4 ×4




Screw
Ø4*39mm

5 ×4



Wall anchor

6 ×2



Tie

7 ×4



Anti-tip
component

8 ×4




Screw
Ø4*20mm

9 ×48+4



Screw
Ø4*15mm

10 ×8




Hinge

11 ×8



Shelf pin

12 ×2



Magnetic catch

13 ×1



Screwdriver

14 ×1




Allen key

Assembly Instructions

Step 1

1.Use screw (3) to attach magnetic catch (12) to the corresponding hole of part (A), tighten screw with screwdriver (13).


3	x 4	Ø3*15mm
12	x 2	Magnetic catch
13	x 1	Screwdriver



Step 2

1.Insert panel (C/D/E) into the corresponding hole of part (A), make sure all holes aligned and use allen key (14) to tighten it as picture show.


14	x 1	Allen key



Step 3

1.Install the bottom (B) into the corresponding holes in the pre-assembly step 2, make sure all the holes line up and tighten it with (14) allen key as shown in the picture.


14	x 1	Allen key



Step 4


1.Install part (H) into the preassembled step 3, make sure all holes aligned and use screw (3) to attach them, tighten screw (3) with screwdriver (13).

3	x 26	Ø3*15mm
13	x 1	Screwdriver




Step 5


1.Attach leg (I/J) to bottom panel (B),screw up the legs.




Step 6



Attention:
Before the next step, adjust the feet of the locker to keep it level.






Step 7

1.Insert shelf holder (11) to the unit pre-assembled at step 6 and attach the part (F/G) to them.


11	x 8	Shelf pin



Step 8

1.Use screw (9) to attach the hinges (10) to door panel (K)&(L)，tighten screws with screwdriver (13)

9	x 16	Ø4*15mm
10	x 8	Hinge
13	x 1	Screwdriver




Step 9


1.Use screw (9) to attach door (K&L) to pre-assemble unit at step 8 ,tighten screw (9) with screwdriver (13) .
2.Use bolt (2) to attach handle (1) to door panel (K&L)，tighten bolts with screwdriver (13)

1		x 4	Hold hands
2		x 4	Ø4*25mm
9		x 32	Ø4*15mm
13		x 1	Screwdriver


Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm mounting screw or via cam adjustment!



Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam adjustment!




Hinge adjustment method

Scan for adj video

Step 10

1.Use screw (8) to attach Anti-tip component (7) to part (A), make sure all holes aligned and tighten screw (8) with screwdriver (13).


8	 x 4	Ø4*20mm
7	 x 2	Anti-tip component
13	 x 1	Screwdriver




Step 11


1.Install Anti-tip device (7) to the wall in this step.

7	x 2	Anti-tip component
4	x 4	Ø4*39mm
5	x 4	Wall anchor
13	x 1	Screwdriver






1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device (7) to the wall with screws (4)

Step 12

1.Let the plastic belt (6) pass through the both part (7) and pull tightly.

6	x 2	Tie


⚠WARNING



Children have died from furniture tipover.To reduce the risk of furniture tipover:

-ALWAYS install anti-tip device provided.
-NEVER put a TV on this product.
-NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!



WWW.HULALAHOME.COM
Email: customerservice@hulalahome.com
Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)