

NOTICE

*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com.

PREPARATION

* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

* If any part is missing or damaged, do not attempt to assemble the product.

* Estimated Assembly Time: 10 minutes.

* Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

OUTDOOR FURNITURE CARE

Store outdoor furniture indoors or cover well when not in use. Remove wooden furniture from standing water.


Dust regularly with small brush or vacuum.

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.



Model# PAT7340

Product Dimensions: 27.6" W x 49.2" D x 15.2" H



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Table Top		1X
B	Leg		4X
HW1	Allen Bolt: M6x0.5x60 mm	 M6x 60	8X
HW2	Washer Ø6.5/20x2mm	 M6.5/20X2	8X
HW3	Washer Ø6.5/14x2mm	 M6.5/ 14X2	8X
HW4	Allen key	 LG4	1X



Weight Capacity :40 Ibs


Warning : Do not stand on table

Warning : Do not over torque bolts / screws

PREPARATION

- *Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time : 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer care team is always here to help. Please email customersupport@safavieh.com


1



Step 1

Place the Table Top (A) (bottom-side up) onto a clean, soft surface to avoid any scratches or damage to the product.
Loosely affix the Legs (B) into the mounting positions at the corners of the Table Top (A), then secure them using the Bolts (HW1) with Washers (HW2),(HW3) and the Allen key (HW4), as shown above

2



Step 2

Turn the Table right side up
Ensure all bolts are fully locked into position.
The Table is ready to be used.