## **USER MANUAL**



# LP32UV

### **UV Illuminator Light 32-LED**





#### **Operation Instructions**

**On/Off:** Press and release the button on the tail cap to turn the light on and off.



#### **Battery Replacement**

The LP32UV uses 4 AAA batteries.

To replace the batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide out the battery case which contains the batteries. Remove the batteries from the case and insert new batteries according to the (+/-) symbols found on the case. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. Re-insert battery case into the flashlight ensuring the side of the case with the metal knob goes first. Re-attach the tail cap by pressing down lightly and turning it clockwise until tight.

#### Features

Operating Ultraviolet light 385-390nm

Constructed with aircraft-grade aluminum

32 UV LED

Enhanced rubber grip

High quality wrist lanyard

Tactical on/off button

IPX4 waterproof rating

Batteries included (4 AAA)



If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.

#### **Product Warranty**

The LP32UV has a Limited Lifetime Warranty Against Manufacturer's Defects.

To submit a warranty claim, please visit our Warranty Page.