EGSEAT

Massage Office Chair



PARTS INCLUDED



A Backrest (x1)



B Seat (x1)



C Lumbar Pillow (x1)



D Armrests (x2)



E Armrest End Caps (x4)



F Backrest Bracket (x1)



G Gas Lift (x1)



H Gas Lift Cover (x1)



I Base Hub (x1)



J Seat Mechanism (x1)



K Base Legs (x5)



L Casters (x5)



M Power Cord (x1)



N Bolts M6 x 20 mm (x10)



O Bolts M6 x 20 mm (x4)



P Bolts M8 x 20 mm (x4)



Q Bolts M8 x 40 mm (x4)



R Bolts M6 x 25 mm (x4)




S Spare Parts (x6)



T Wrench (x1)

ASSEMBLY INSTRUCTIONS

1 Insert the Base Legs (K) into the Base Hub (I) and tighten all Bolts (N) using the Wrench (T).



2 Press the Casters (L) firmly into the holes at the end of each Base Leg (K).



3 Insert the Gas Lift (G) and the Gas Lift Cover (H) into the Base Hub (I).



4 Attach the Seat Mechanism (J) to the Seat (B) with 4 Bolts (O).



5 Push the Seat (B) down onto the Gas Lift.



6 Align the Backrest Bracket (F) with the screw holes. Insert the Bolts (R) and tighten them securely.



7 Insert the Backrest Bracket (F) into the Seat Mechanism (J) and secure it with Bolts (P). Tighten securely.



8 Attach the Armrests(D) to the Backrest(A) and seat(B) using the bolts(Q). Tighten securely.



9 Align the Armrest End Caps (E) with the hole and press firmly until they snap into place.



10 Place the Lumbar Pillow (C) on the Seat (B). Wrap the strap around the Backrest (A) and fasten it securely.



11 Connect the Power Cord (M) to the Massage Unit and plug it into a wall outlet.



12 The installation is now complete. Before use,please ensure that all components are securely assembled.




PRODUCT FEATURES OVERVIEW



Massage & Heating Controls

Massage Power — Press to toggle massage on/off.
Heating Power — Press to toggle heating on/off.
Massage Direction — Press to change direction;
press again to restore original.
Note: When both functions are on, the indicator light flashes



Footrest Adjustment

Slide the footrest forward until fully extended.
Rotate into open position for use.



Backrest Tilt Lock

Lift the front lever to recline to your preferred angle.
Push down to lock in place.



Seat Height Adjustment

While seated, lift the rear lever to lower the seat.
When not seated, lift to raise the seat.

SAFETY INFORMATION



Do not push the chair when occupied.



Do not apply force to the backrest when reclined.



Do not lean with full weight on the backrest.



Do not stand on the chair.



Do not use the chair for more than one person at a time.



Do not sit on the front edge of the seat.



Always sit centrally with your back supported.

Weight limit:<**500** lbs.



You Tube | ASSEMBLY VIDEO

Thank you for choosing our chair.
We value and appreciate your feedback.
For assistance or comments,
please reach us at:
support@egseat.net