


ASSEMBLY INSTRUCTIONS


POWER RECLINER STORAGE CHAIR WITH USB & WIRELESS CHARGER & LED & SPEAKERS

A Seat




1PC

B Backrest



1PC

C Adaptor




1PC

D Plug with Wire




1PC




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Attach the Backrest (B) to the Seat (A) using the brackets as shown. Ensure the brackets are secured in position.




- 2** Use Velcro to attach the back cover of the Backrest (B) to the bottom of the Seat (A).




- 3** Storage box opening method.



- 4** Connect the wire from the Seat (A) to the Adaptor (C) and the Plug with Wire (D), then plug it into the socket.



- 5** Introduction to Control Switches.



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.