TV cabinet installation instructions



https://youtu.be/-90mmti2BCc

https://gumlet.tv/watch/69cdd51e1763b418bf091471/

Installation video link

(Different links, both of which can be tried)

Maintenance Instructions

A. Daily Cleaning and Maintenance

1. Regular Dust Removal: The interior and back of the TV cabinet are prone to dust accumulation, and should be wiped regularly with a clean soft cloth. For daily cleaning, it is recommended to use a wrung-out wet towel to gently wipe the surface to avoid scratching the paint.

2. Treatment of Stubborn Stains: If there are stubborn stains on the surface, they can be gently wiped away with warm tea, followed by applying a small amount of special polish to restore the luster. For wooden TV cabinets, a dedicated wooden furniture cleaner can also be used.

3. Maintaining Luster: To ensure the surface of the TV cabinet remains bright, it can be wiped regularly with a cloth dipped in diluted olive oil (mixed with water). Every six months or a year, a wooden maintenance oil can be applied to solid wood TV cabinets to maintain their luster and waterproof performance.

B. Usage Environment and Placement Requirements

1. Stable Placement: The TV cabinet should be placed on a flat floor to avoid structural deformation due to uneven ground. At the same time, it needs to be kept away from sharp objects and heavy objects to prevent scratches or dents.

2. Control Temperature and Humidity: Solid wood TV cabinets are sensitive to environmental temperature and humidity. They should be placed away from heat sources (such as radiators) and direct air conditioning blows to avoid wood cracking due to drastic temperature changes. When the interior is humid in summer, moisture prevention should be taken into account by leaving a gap of 0.5 to 1 cm between the TV cabinet and the wall, or by laying a moisture-proof pad at the bottom.

3. Avoid Direct Sunlight: The TV cabinet should be avoided being exposed to sunlight for a long time to prevent wood discoloration and aging.

C. Precautions for Use and Operation


1. Gently Operate: When opening or closing cabinet doors or drawers, the action should be gentle to avoid structural damage caused by excessive force.

2. Prevent Scratches: Avoid using hard objects or sharp objects to collide or scratch the surface of the TV cabinet, as once damaged, it is difficult to recover. At the same time, chemicals that may corrode the wooden surface should be avoided.


3. Reasonable Load Bearing and Placement: A suitable space should be reserved above the TV cabinet for placing items, but excessive heavy items should not be placed on it. If plants are placed on the TV cabinet, it is advisable to choose varieties with lush foliage and avoid placing plants with thorns (such as cacti).

By following the above maintenance methods, the appearance and functionality of the TV cabinet can be effectively maintained, ensuring it remains as good as new for a long time.

(It is recommended to assemble by 2 people)



TV cabinet board number



STEP:1 Open the package and locate the accessory kit








STEP:2 Lay all the wooden boards flat on the ground



STEP:3 Assemble the bottom frame of the foot




STEP:4 Assemble the drawer



STEP:5 Install drawer slide rail






split guide rail

















STEP:6 Install the side panels and back panel














STEP:7 IInstalling the vertical panel












STEP:8 Installation of side panels and vertical panels













STEP:9 Install the drawer















STEP:10 Install the hinge for the middle down-folding door



















THE END!