








ASSEMBLY INSTRUCTIONS



We recommend at least 2 people for the assembly.





To prevent any damage during assembly, place a mat under the pieces.



Any questions concerning assembly, contact us via email


⚠ Warning	Flammable, please keep away from open flames!
⚠ Warnung	Entflammbar, bitte von offenen Flammen fernhalten!
⚠ Attention	inflammable, veuillez tenir à l'écart des flammes nues !
⚠ Attenzione	infiammabile, tenere lontano da fiamme libere!
⚠ Advertencia	Inflamable, mantener alejado de fuego!
⚠ Waarschuwing	Ontvlambaar, uit de buurt van open vuur houden!
⚠ Ostrzeżenie	Produkt łatwopalny, trzymać z dala od otwartego ognia!

PARTS DIAGRAM



HARDWARES


 The spare parts are the additional parts provided in case of missing or damaged ones. Keep the spare parts and tools for future use.




M6x35mm
A x 14



M15x10mm
B x 14



φ6x30mm
C x 18




M4x35mm
D x 8



M4x10mm
E x 2



M4x14mm
F x 20




G x 4



M6x35mm
H x 2



M3.5x14mm
I x 2



The product comes with a plug that varies by market. The one actually received shall in kind prevail.
J x 1




K x 4



M3x16mm
L x 4

SPARE PARTS


 The spare parts are the additional parts provided in case of missing or damaged ones. Keep the spare parts and tools for future use.



M6x35mm
A x 1



M15x10mm
B x 1



φ6x30mm
C x 1





M4x14mm
F x 2


CAM LOCK FASTEN SYSTEM

 Insert the cam bolt into the hole, then insert the cam lock and tighten.


1



2




3



Point the opening towards the edge of the board.

4







>90°




UNLOCK LOCK

ASSEMBLY




1





2






3






4




5






6




7





8





9




10





11





12



13




14




Insert back panel clip into gap.

Secure with screw.



15



单页尺寸：210*290mm

张开尺寸：420*290mm

骑马钉

材质：封面128克铜版纸

内页80g书纸

单色印刷