

























Assembly Instruction



① X2 	② X2 	③ X1 			
④ X2 	⑤ X2 	⑥ X2 			
⑦ X1 	⑧ X2 	⑨ X1 	⑩ X2 	⑪ X2 	
⑫ X8 	 ⑬ X4 ⑭ X2 ⑮ X2			⑯ X1 	
⑰ X1 	⑱ X1 	⑲ X2 			
⑳ X2 	㉑ X2 	㉒ X2 			
㉓ X2 	㉔ X4 	A X1  M6X30	B X3  M6X70		
C X18  M6X60		D X4  M6X45		E X15  M6X35	F X2  M6X10
G X8  M8X50	H X4  M8X12	I X6  M6	J X9  M6	L X16 	

Difference screws display(1:1)

A

M6X30

B

M6X70

C

M6X60

D

M6X45

E

M6X35

F

M6X10

G

M8X50

H

M8X12

I

M6

M6:Screw outer diameter 6mm

M8:Screw outer diameter 8mm

Step 1

A

M6X30

1

E

M6X35

1

Please do not tighten the E - screws for now, but tighten the A - screws.

Step 2

C

M6X60

6


1

Step 1

1


Please do not tighten the C - screws for now

Step 3




After assembling the E - screws, please tighten the screws from the previous two steps


Step 4



Step 5




Step 6



Step 7


F	M6X10	2
---	-------	---



2PCS


Step 8

D	M6X45	2
G	M8X50	4




Step 9

D	M6X45	2
G	M8X50	4




Step 10

H	M8X12	4
---	-------	---




Step 11


B	M6X70	3
J		3




Step 12




Step 13



Step 14



Step 15

 L=16PCS

