








Installation & Assembly




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.













EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.























EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.








EN_Turn cam lock clockwise to tighten.

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x1	
⑥		x1	
⑦		x1	
⑧		x1	
⑨		x1	
⑩		x2	



NO.		QTY	SPARE
⑪		x1	
⑫		x1	
⑬		x1	
⑭		x1	
⑮		x1	
⑯		x1	
⑰		x1	
⑱		x1	
⑲		x1	
⑳		x1	



NO.	PARTS	QTY	SPARE
21		x1	
22		x1	
23		x1	
24		x1	
25		x1	
26		x1	
27		x1	
28		x3	
29		x3	
30		x3	





NO.		QTY	SPARE
31		x3	
32		x3	
33		x3	
	 Hardware Kit		



A x45 Ø6x35mm +3(spare)	B x47 Ø15x10mm +3(spare)	C x56 Ø6x30mm +3(spare)	D x48 Ø4x35mm +3(spare)	E x65 Ø3.5x12mm +3(spare)	F x4
G x8	H x1 Ø3x14mm	I x1	J x4	K x22 Ø3x16mm +2(spare)	L x3
M x1	N x2 Ø3.5x12mm	O x2	P x1	Q x9	R x1
S x49 +4(spare)	T x2				
CL x3 L350mm	CR x3 L350mm	DL x3 L350mm	DR x3 L350mm		


D x15**01****x3**

A x15 	B x15 	C x6 	E x18 	F x3 
G x6 	DL x3 	DR x3 		


02
x3


E x9

CL x3




Attention,
first hole




E x9

CR x3




Attention,
first hole





05


C x2




D x4



A x3




06




B x3




C x2




C x4







H x1




C x6





D x8



C x6




D x8




E x3




L x3





C x4




D x6




E x1






A x11



16





B x11



E x2




17




Need Two or More
People To Complete


A x8



M x1




N x2




B x8




C x8






O x2



B x2



C x1




E x9



Q x9






R x1












he installation direction can be
chosen according to your needs.

A x8













To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.





To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.




Turning the screw "C" on BOTH hinges on each door.





(1)



(2)







Scan QR code to download
APP controller

OR

Flip to the other side to
find the control button

