

# ASSEMBLY INSTRUCTIONS

Only the technical personnel can be allowed to fix and maintain.

## IMPORTANT!

Ensure that the power is switch off at the electricity mains supply before commencing work.

## GENERAL INSTRUCTIONS

Install the parts according to the bag as shown in figure 3 shows, installed Taiwan screw, and should be fixed to the ceiling in the right place. and Connection (See picture 1): there are one tapping hole & two screws.

Connect the supply ground wire (2) on the green ground screw (15) and then put the canopy up to the ceiling and Lock cuttlefish nut.

Connect the fixture ground wire (3) with supply ground wire connecting terminal (12). Caution: DO NOT connect ground wire with power wire.

Connect the fixture supply wire with power supply wire. Caution: Remember to distinguish the positive and negative charges. (See picture 2) canopy up to the ceiling and Lock cuttlefish nut.

## INSTALLATION OF BULB

Do not exceed the maximum wattage. Bulbs recommended: E12 3x40W Max. Type B.

## MAINTENANCE CARE

Clean with a soft dry cloth.

## ADDITIONAL INFORMATION

The bulb must be in rated voltage, and do not touch the bulb with bare hands. After use, switch off the electricity supply and allow to cool for 10 minutes before hanging the light bulbs.

If the external cables have been damaged, please change or repair by the manufacturer or service agency or professional electrician. In order to avoid danger.

