


USE AND CARE GUIDE

15 INCH COLLAPSIBLE FIRE PIT - STAINLESS STEEL



Questions, problems, missing parts? Before returning to the store,
send email to cbec@china-yayi.com

Table of Contents

Table of Contents.....	2
Safety Information.....	2
Warranty.....	3
What is Covered.....	3
What is Not Covered.....	3
Pre-Assembly.....	3

Package Contents	4
Assembly.....	5-7
Operating Instructions.....	8
Maintenance.....	8
Care and Cleaning.....	8

Safety Information

PLEASE READ AND UNDERSTAND THIS ENTIRE MANUAL BEFORE ATTEMPTING TO ASSEMBLE, OPERATE OR INSTALL THE PRODUCT.



WARNINGFor outdoor use only!
Never leave a fire unattended!



WARNINGDo not burn over 4 lb untreated wood or fire logs in this fire pit.



WARNING:Never leave the burning fire bowl unattended, and always extinguish the fire completed.



WARNING:Do not allow children or pets near fire pit without supervision.



WARNING:Do not touch the surface of the fire pit while in use as it may cause burns.



WARNING:Never burn in vehicles, tents or indoors.
CARBON MONOXIDE HAZARD.



WARNING:Do not use water to extinguish as this is dangerous and can cause damage to the fire pit.



CAUTIONBurn only untreated wood, fire logs or wood pellets in this fire pit.



CAUTIONDo not use gasoline or kerosene to start the fire in this fire pit.



CAUTIONDo not use this unit on a wood deck, long or dry grass and/or leaves, or on combustible surfaces.



CAUTIONDo not attempt to move the fire pit while it is hot or in use.



CAUTIONPlace the fire pit no closer than 8 ft. from walls or combustibles during use.



CAUTIONAdequate fire extinguishing material should be readily available.



CAUTION:Do not use this fire pit in windy conditions.



WARNING: FUELS USED IN WOOD OR CHARCOAL BURNING APPLIANCES, AND THE PRODUCTS OF COMBUSTION OF SUCH FUELS, CAN EXPOSE YOU TO CHEMICALS INCLUDING CARBON BLACK, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, AND CARBON MONOXIDE, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. For more information go to: www.P65Warnings.ca.gov

Warranty

1 YEAR LIMITED WARRANTY

WHAT IS COVERED

We warrant the metal frame to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production. Contact the Customer Service Team at cbec@china-yayi.com.

Pre-assembly


PLANNING ASSEMBLY

Carefully remove all pieces from carton and make sure that you have all parts (refer to the Package Contents list). If you are missing parts, please contact cbec@china-yayi.com for further assistance.



NOTE: Please read and understand the entire manual before you operate the fire pit.

Package Contents




Part	Description	Quantity
A	Grill Grate	1
B	Fire Ring	1
C	Stove Chamber	1
D	Stove Base Plate	1
E	Ash Pan	1
F	Bottom Vents	1
G	Carry Bag	1
H	Poker	1

Assembly


1 Take out all the parts

- ☐ Take all the parts from collapsible packed fire pit.




2 Put into ash pan

- ☐ Put Ash Pan (E) into Bottom Vents (F)




3 Place stove chamber

- ☐ Turn the Stove Chamber (C) upside down, put it onto the Bottom Vents (F).



4 Place stove base plate and fire ring


- ☐ Place Stove Base Plate (D) into Stove Chamber (C)
- ☐ Place Fire Ring (B) onto Stove Chamber (C)



Assembly (continued)


5 Place grill grate

- ☐ Remove Fire Ring and place the Grill Grate (A) onto Stove Chamber (C) if necessary.



6 Collapsed fire pit

- ☐ Collapsed fire pit in the reverse order of the Step 1
- ☐ Use carry bag included for portable carrying



Operating Instructions

Lighting

- ☐ Place a layer of dry seasoned hardwood (Recommend using wood log size within Dia 2 in x L10.3 in).
- ☐ Use a long match or stick lighter to light.
- ☐ Add additional logs as needed.
- ☐ Please wear heat-resistant gloves during use.



NOTE: When first lit, there will be some smoke, which will decrease over time as the unit achieves full efficiency.

Extinguishing the Fire

- ☐ Allow the fire to burn itself out.
- ☐ Use sand or put on a metal lid over the fire bowl to extinguish the fire.
- ☐ Except in the event of an emergency, do NOT use water to extinguish a fire as this is dangerous and can cause damage to the outdoor fire pit.

Maintenance

- ☐ Due to extremely high temperatures, discoloration of the fire pit will occur and is considered normal.
- ☐ To extend the life of your fire pit, clean it after each use.
- ☐ To protect fire pit finish, use a soft cloth in lieu of bare hands while handling.
- ☐ Clean the fire bowl after each use once ashes have cooled.
- ☐ Store assembled fire pit in a cool, dry location away from children and pets.

Care and Cleaning

- ☐ Do not attempt to clean the fire pit until the fire is completely out and cooled completely.
- ☐ Carefully take out Ash Pan from Bottom Vents, pull out the ash and clean the Ash Pan and fire pit with a soft cloth (Figure 1).
- ☐ Keep the fire pit covered when cooled and not in use.




Figure 1