

ASSEMBLY INSTRUCTION


SHAKER DINING TABLE


Before you begin, Please follow Assembly Instruction carefully. Then follow them step by step.

PART LIST


A	TABLE TOP	1 PC
B	TABLE LEGS	4PCS

HARDWARE LIST

C	 HEX SCREW	8 PCS
D	 FLAT WASHER	8 PCS
E	 HEX WRENCH	1 PC
F	 SPRING WASHER	8 PCS





IMPORTANT NOTE : PLACE ALL WOODEN PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
FIX THE TABLE LEGS(B) TO THE CORNER BLOCK WITH HEX SCREW (C) SPRING WASHER (F), AND FLAT WASHER (D). THEN TIGHTEN THE HEX SCREW(C) BY USING THE HEX WRENCH(E).



MADE IN MALAYSIA

ASSEMBLY INSTRUCTION

DINING CHAIR



PARTS CHECK - LIST

CODE	COMPONENT	QTY
(A)	BACK STAND	X 1
(B)	SIDE RAIL	X 2
(C)	FRONT LEG	X 1
(D)	STRETCHER	X 2
(E)	SEAT	X 1

FITTING CHECK - LIST


CODE	COMPONENT	QTY
(01) JCBC		X 6
(02) SPRING WASHER		X 6
(03) FLAT WASHER		X 6
(04) ALLEN KEY		X 1
(05) CSK SCREW X 38mm		X 4
(06) CSK SCREW X 30mm		X 4
(07) FELT PAD		X 4

TOOL NEEDED PHILLIP HEAD
(NOT PROVIDED) SCREW DRIVER

1. Please do not discard any of the packing until you have checked all the part of the fitting.
2. Please retightens the screw every six months.
3. Maximum load bearing - 100kg (200lbs).
4. Before you begin to ensure to assemble your new piece of furniture, please check to ensure that all part have been supplied.
5. Follow instruction closely as deviation from may void your warranty and present a possible safety risk.
6. It is recommended that assembly is done on a soft surface like carpet to avoid any damage.
7. Periodically check and re-tighten any fasteners. Wipe down all surface weekly with a clean cloth. Do not clean any surface with harsh abrasives or chemicals.


1.

Attaching Side Rail and stretcher to front leg - Do not fully tight



2.

Attaching assembly leg to back stand



3.

Attaching seat frame to assembly leg with CSK screw
- Re-tighten all the bolt and screw

