




Instruction Manuals

Caution: You must read this before you proceed

Fire Screen




Step 1




Catch the left handle and pull it along the direction of arrow slowly as shown.

Step 2



Catch the right handle and pull it along the direction of arrow slowly as shown.

Step 3



Your Fire Screen is ready for use.

Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.