




Assembly Manual

Thank you for your purchase at our store.

Please contact us directly if you have difficulty with assembly or need replacement parts. Professional customer service is here to assist you.

Email: emarthome@hotmail.com


Please call for replacement parts or assistance: 1-478-666-6611. Mon-Fri 7am-4pm (PST), Mon-Fri 10am-7pm (EST).

Please attach your order ID or some photos related so that we could help you better.

Two people are recommended to install, which will greatly improve your installation efficiency.

Tips Before Assembly


1. Read through each step carefully and follow the proper order.
2. Identify, sort and count all the parts with tags.
3. To avoid any scratching, putting a soft blanket on the floor is suggested.
4. If using a power drill or power screwdriver for the screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.
5. Put the screws in loosely until all pieces are together and then tighten them all. It will save your time if you make a mistake while installing.



Using Camlocks


Connect the male camlock as directed in the assembly instructions using a screwdriver.

1 DO NOT OVER TIGHTEN



Push the male camlock into the entry hole.


2



Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points toward the entry hole for the male camlock.

3




Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4




HOW TO ADJUST THE EUROPEAN ADJUSTABLE HINGES ON DOOR


If the doors require adjustment, follow the below options as needed:

To adjust door up or down, loosen screws (a), adjust door and retighten screws.
























To adjust door left and right, turn screw (b) in or out.

To adjust door in and out, loosen screw (c), adjust door and retighten screw.





















PART LIST

A  1 pc	B  1 pc	C  1 pc	D  1 pc
E  1 pc	F  1 pc	G  2 pcs	H  1 pc
I  1 pc	J  1 pc	K  1 pc	L  1 pc
M  1 pc	N  1 pc	O  3 pcs	P  3 pcs
Q  3 pcs	R  3 pcs	S  2 pcs	T  3 pcs
U  3 pcs	V  2 pcs	W  2 pcs	


HARDWARE LIST

①  M6x40 60 pcs	②  M4x14 36 pcs	③  M4x12 4 pcs	④  M3x16 34 pcs
⑤  M3x12 36 pcs	⑥  M6x28 38 pcs	⑦  Ø12 38 pcs	⑧  M4x20 10 pcs
⑨  L300 3 pcs	⑩  L300 3 pcs	⑪  L300 3 pcs	⑫  L300 3 pcs
⑬  Ø35 6 pcs	⑭  5 pcs	⑮  M4x40 2 pcs	⑯  56-100cm 1 pc
⑰  1 pc	⑱  1 pc	⑲  L918 1 pcs	⑳  L419 1 pcs
㉑  M4 1 pc	㉒  1 pc	㉓  8 pcs	㉔  Ø10 2 pcs


STEP 1




STEP 2





STEP 3






STEP 4




STEP 5




STEP 6



STEP 7





STEP 8





STEP 9



Keep the holes of the Part I
as shown.




STEP 10








STEP 11





Gently tap the Floor Protectors (23) at the bottom of side panels avoiding crack or damage of side panel.





STEP 12



STEP 13





STEP 14






STEP 15

x3







STEP 16





x3

STEP 17




STEP 18




Please put the wheels align with the slots as the instruction shows, then slide into them

STEP 19




Note: Twist the expandable pole clockwise to tighten. anticlockwise to loosen.





STEP 20




STEP 21




STEP 22




STEP 23



STEP 24




STEP 25





STEP 26

TIPPING RESTRAINT HARDWARE



Note: We have included two Tipping Restraint Hardware set for this Unit. When properly installed, this restraint can provide protection against the unexpected tipping of the Unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your Unit.

Note: You must install the Tipping Restraint Hardware with the unit in use to prevent any accidents or damage to the unit.



Please unscrew the Part ① screw first, then install Part ⑮.

