

ASSEMBLY INSTRUCTION

ltem No.:S24




Components List


1PL:




G x1




H x1



I-L x1




J x1




K x1


Hardware List



ST:




L X1




M x1

Hardware List




STEP 1




STEP 2


	Ax6




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9






Please hold and adjust the gear with both hands.




STEP 10


	Ax4




STEP 11



STEP 12



STEP 13



QUESTIONS? CONTACT US:

- Email:customerservice@hkfoam.com

If in any case, you are not 100% happy with the item received,would you please contact us first and give us a chance to make it right for you? All of our products are covered by warranty and we will do our best to address any of your concerns. We are dedicated to your 100% satisfaction with your order.