

DREAMS

IDEA

Instruction Manual





ASSEMBLY INSTRUCTIONS


Tel.(562)-781-3327

Please contact us:info@firstopintl.com

<https://www.dreamsidea.com>


EXPLODED

— VIEW



PARTS

AX1



Fixture

BX1




Lightshade

CX1



Screw

DX1



Iron ring

EX1



Finial

ATTENTION

Please inspect the wires before installation, if the wire shows any cut or abrasion, or has exposed copper wires, DO NOT use the fixture, it might be caused during transportation or defect product.

Before starting installation of the fixture, please remove the previous fixture (if any).

Disconnect the power by turning off the electric break for your property (Please ask for professional help if needed).

MAINTAINANCE AND WARNING

Verify the lamp model suits the environment (indoor/outdoor, IP rating) and check all accessories (body, screws, cord, manual).

Only use with bulbs of the recommended type and wattage. Exceeding the maximum wattage may cause overheating or fire.

Do not install the fixture if any part is damaged or missing. Contact the manufacturer or seller for replacement parts.

The fixture may become hot during use. Allow to cool before handling.


Clean dust accumulation in recessed lamps regularly (to prevent overheating), but only when powered off; never rinse with water.

If the fixture includes a dimmer switch, ensure it is compatible with the fixture before installation.

Do not modify the fixture in any way; tampering with electrical components can result in malfunction or risk of fire.


step 1 ---Install the screw (C)

Install the screw (C) into fixture (A).



step 2 ---Install the lamp bulb.


Install the lamp bulb.



step 3 ---Install the Lightshade & Iron ring


Install the Lightshade (B) into fixture (A).

Install the Iron ring (D) into Lightshade (B).





step 4 ---Install the Finial (E)

Install the Finial (E) into Iron ring (D).




step 5 ---Light-control

This lamp is controlled by adjusting the switch to regulate the brightness.



step 6 ---Assembly complete



Product Overview



2005-S



2005-M

