


How To Use the Super Switch



To program your presets simply bring the Desktop to your desired height and press the “S” button, followed by the number you would like to save it to.