


## Daily Maintenance



(Fig.1)

1. Take out the drainage tray to drain the waste water regularly as shown (Fig. 1).
2. Utilize a wet cloth to clean the surface of the towel warmer for better outlook.

## Troubleshooting Checklists

Issue(s)	Possible Cause(s)	Solution(s)
The appliance could not be turned on.	<ol style="list-style-type: none"><li>1. Inner circuit and wires are loosened.</li><li>2. The fuse at the back is broken (Fig.2).</li></ol>	<ol style="list-style-type: none"><li>1. Check the connection of the power cable and the inner circuit line. Reconnect them to see if the problem could be solved.</li><li>2. Replace the fuse.</li></ol>
The door could Not be fully closed.	The screw on the door hinge is loosened.	Retighten the screws and readjust the door's position.





Fig.2

# Towel Warmer User Manual




## Safety Instructions

1. Power applied should match the rated power of the appliance itself.
2. Children are not allowed to operate this appliance for safety concerns.
3. Place the appliance on a flat, level and solid surface.
4. If you want to sterilize wet towel, make sure that the wet towel is not dripping water. If it is dripping water, wring it first before putting it into the appliance.
5. Remember to dry the stagnant water inside the appliance regularly.  
Remember to disconnect the power first before you do this.
6. Take out the sterilized items from the appliance with tweezers instead of bare hands.
7. Never use any corrosive detergents to clean the appliance and its iron shelves.
8. Never open or close the door of the appliance with too much force.
9. Keep the appliance away from explosive and flammable material. Ensure that the distance between the appliance and the surrounding material is at least 30 cm.
10. Always ensure the door of the appliance is closed when it is working.


## Specifications

<b>Overall Dimensions (LxWxH)</b>	8 7/16" x 10 3/8" x 11 11/16" (21.4 x 26.4 x 29.7 cm)
<b>Voltage</b>	110 V, 60 Hz
<b>Power</b>	200 W
<b>Heating Temperature Range</b>	158 to 176 °F (70 to 80°C)
<b>Tank Capacity</b>	5 L
<b>Net Weight</b>	6.35 Lbs (2.88 kg)

## Package Contents



Towel Warmer x 1




Shelf x 1



Power Cord x 1


## Assembly Instructions

1



Open the towel warmer and place the shelf into it.

2



Connect power cord to the towel warmer.

## Operation Instructions



Press the power button to start heating.