

DOUBLE HAMMOCK STAND

914920, 914921, 914922

MAX Capacity: 550 lbs

Dimensions: 9 ft. X 3 ft.

HARDWARE

❶ Hook, Wingnut, & Washer Set (2)

❷ Knob Screw (5)

PARTS

Ⓐ Base (2)

Ⓑ Cross Bar

Ⓒ Hammock
Frame Bar (2)

Ⓓ Carrying Bag

Ⓔ Double Hammock

IMPORTANT:

- Firmly secure all screws before use.
- Product is intended for outdoor use.
- If any parts are missing, broken, damaged, or worn, *stop* using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with manufacturer's instructions as this could void the product warranty.

CAUTION: MAX Capacity: 550 lbs

- Ensure hammock stand is on level ground for proper balance.
- Do *not* leave children unattended while on hammock.
- Do *not* use hammock or stand as a swing.
- Always enter hammock from middle.
- Do *not* sit past base legs of hammock stand.
- Ensure the hook and wingnuts are secured on a regular basis.
- Inspect hammock and frame for signs of deterioration or damage frequently. Do *not* use this product if worn or damaged.

IMPORTANT:

Install hook on the side that is facing away from hammock. See the close up image of hardware #1.

