

CHANDELIER



CHANDELIER

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.



- 1. Measure area and determine desired hanging height.
- Product comes with two (2) 24", one (1) 12", one (1) 8" and one (1) 4" hard stems [A] for adjustable hanging height. Determine the stems you will use to achieve desired height. (Threads are removable from the stems and thread removal may make it easier to thread wire.)
- Thread wire [E] from upper hub [B] through first stem [A]. Continue to add stems, threading the wire and screwing each stem together. Repeat as necessary to achieve desired hanging height.
- **4.** Detach mounting plate [C] from canopy [D]. Thread wire [E] through canopy.
- 5. Mounting plate [C] will attach to ceiling junction box.
- Connect the fixture body [G] to the upper hub [B] by hooking each fixture arm [H] into the corresponding top and bottom eyelets [I].
- Install light to ceiling. We recommend installa-tion by a qualified electrical professional. Canopy nuts [F] are used to tighten light to ceiling.
- 8. Install included bulbs.

