

EVA 7-Piece Dining Set

Assembly Instructions

Important: Do not fully tighten any bolts or screws until the entire dining set has been assembled.

Part	Description	Qty
A	Table Top	1
B	Table Legs	4
C	Chair Back	6
D	Chair Seat	6
E	Chair Legs	12

Assembly

1. Place the table top upside down on a soft surface and loosely attach all four table legs.
2. Attach each chair back to its chair seat using the supplied bolts, washers and spring washers.
3. Attach the chair legs to each assembled chair. Repeat for all six chairs.
4. After confirming proper alignment, tighten all hardware securely.
5. Place the set upright and check stability before use.