


SWOOP Kids Chair




ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll- free customer service number and have this assembly manual open to the parts list ready to provide the model name, and part name or number.




PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



A. Seat Body 1x



B. Leg 4x



C. Washer 4x

ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.

Please turn chair frame upside down. Attach wood legs by inserting threaded post into insert nut. Hand Tighten until tight.

